

Philips
Lid for water
container

• SENSEO® Up

CP9056/01



Covers the SENSEO Up water container

Go to the Specs Tab to check your matching product

This lid covers the water container of your SENSEO Up machine. Easy to remove and clean!

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

PHILIPS

Specifications

Replaceable part

- Fits product types:: HD7880/10, HD7880/11, HD7880/40, HD7880/41, HD7880/70, HD7880/

71, HD7880/80, HD7880/81, HD7880/86, HD7880/87, HD7884/30, HD7884/31, HD7884/60, HD7884/61, HD7884/80, HD7884/81

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2024-01-14

Version: 5.5.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com