



① Cap

② Mouthpiece

3 Pop-up button

4) Lid

⑤ Filter cartridge

6 Straw

Bottle

8 Carry loop





Get started

1. Cleaning the bottle

Unscrew the lid and remove the straw, clean all the components except for the filter cartridge with a mild detergent by hand or in the dishwasher (max $50\,$ °C).

2. Preparing and installing the filter

Take the filter out of the packaging and rinse it under tap water for 10 seconds.

Unscrew the lid and remove the straw. Insert the filter cartridge into the straw, and reattach the straw back to the lid and twist it tight.

3. Filling the bottle

Fill the bottle with tap water up to the max line (for Everyday bottle only). Screw the lid back on to the bottle. Now take a sip and enjoy!

01

4. Changing the filter cartridge

One filter can filter up to 150 litres of tap water. To ensure optimal filtration and hygiene, it is recommended to replace the filter every 4 weeks. To do this, repeat step 2.

Caution

- GoZero™ Everyday bottle is made with BPA-free Tritan, and GoZero™ Everyday Insulated bottle is made with food-grade 18/8 stainless steel. When used with the Everyday filter, the bottle can only be filled with municipally treated ambient tap water (5°C to 38°C/41°F to 100°F), which is safe to drink according to legal regulation.
- When the filter is removed, the Everyday bottle and Everyday Insulated bottle can be filled with water of 0°C to 55°C/32°F to 131°F. When filled with hot water, please be careful, in case it splashes out when you open the cap.

02

Consume the water in the bottle within a day.

• If an instruction is given from the authorities that mains water must be boiled, then the filtered water by this bottle must also be boiled. When the instruction to boil water is no longer in force, the entire bottle must be thoroughly cleaned, and filter replaced. For some groups of people (e.g. those with impaired immunity and babies), it is recommended that tap water should be boiled, which also applies to the filtered water by this bottle.

• Do not fill the bottle with water that is microbiologically unsafe or of unknown quality without adequate disinfection.

 The filtration of particles from the tap water may result in a significantly lower flow rate. In such cases, we recommend to change the filter more frequently.

03



Specifications are subject to change without notice www.philips.com/water

© 2021 AquaShield

The Philips trademark and the Philips Shield Emblem are registered trademarks of Koninkliike Philips NV. used under license.

This product has been manufactured by and is sold under the responsibility of Hong Kong AquaShield Health Technology Company Limited and Hong Kong AquaShield Health Technology Company Limited is the warrantor in relation to this product.

Rev B MAR 21

 When not using your GoZero™ Everyday, or Everyday Insulated bottle for a long period of time, the bottle should be disassembled and stored completely dry. If the filter hasn't been used for more than 2 days, rinse it under the tap water for 1 minute; if it hasn't been used for more than 10 days, the filter should be replaced.

- When not using the filter for more than 2 days, please dry the filter, store it in a sealed plastic bag and keep it in the refrigerator (not the freezer).
- Always store spare filters in a cool, dry place and ensure that they are tightly sealed.
- Do not microwave and do not store the bottle and filter in the freezer.

Guarantee & Service

If you need information or if you have any problems, please visit the Philips website at www.philips.com or contact the consumer care center in your country. If there is no consumer care center in your country, go to a local dealer.

Thank you for being part of the solution, and helping to reduce single-use plastic waste.

04