Philips Shaver series 7000 shaving unit bottom assy



CP1416

To connect the parts of your shaver

Check compatibility data

This bottom plate is an essential part of your shaving device. The plate is necessary to attach the shaving heads to the body of your shaver. Is your current bottom plate lost or broken? Order a new one here!

Ease of using Philips spare parts

• Easily renew your product with original Philips parts



Specifications

- Replaceable part
 Fits shaver type:: S7910, S7930, S7940, S7950, S7960, S7970
- Fits Product types: S7930/16, S7960/17, S7970/26, S7910/16, S7940/16, S7970/17, S7970/19

Highlights

Easy replacement of product parts
From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2022-10-15

Version: 2.2.1

© 2022 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com