Philips Brush	
CP0913	

A brush for keeping your device clean.

Use this brush to clean the hard-to-reach corners of your device.





Replaceable part

Fits Grooming: BT7201, BT7202, BT7203, BT7204,

BT7205, BT7206, BT7210, BT7215, BT7220



Issue date 2022-10-19

 $\textcircled{\mbox{\sc c}}$ 2022 Koninklijke Philips N.V. All Rights reserved.

Version: 1.1.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com