



Philips
børsteenhed

til forskellige shavere

CP0324

Et ekstra værktøj til din shaver

Tjek kompatibilitetsdata.

Med denne børsteenhed kan du bruge børsten på din shaver

PHILIPS

Specifikationer

Reserveredel

- Passer til produkttypen: S720/17, S728/17, S728/20, S5008, S5010, S5011, S5013, S5015, S5050, S5070, S5075, S5077, S5078, S5079, S5080, S5081, S5085, S5205, S5355, S7310, S7311, S7320, S7370, S7510, S7520, S7530, S7550, S7710, S8950, S9090, S5090, S5095, S5210, S5211, S5230, S5270, S5271, S5340, S5360, S5370, S5380, S5390, S5391
- Passer til produkttyperne: S9021, S9031, S9041, S9111, S9112, S9121, S9151, S9152, S9161, S9171, S9311, S9321, S9371, S9511, S9521, S9522, S9531, S9711, S9712, S9721, S9731, S9911
- Passer til produktfamilien: S5082, S5086, S5091, S5212, S5213, S5231, S5251, S5252, S5272, S5273, S5290, S5335, S5355, S5395, S5396, S7310, S7320, S7371, S7510, S7521, S7522, S7530, S7550, S7720, S7920, S8860, S8880, S8980, S9211, SP9811, SP9851
- Passer til produkttypen: S5100, S5110, S5130, S5140, S5150, S5210, S5211, S5230, S5270, S5271, S5310, S5320, S5330, S5340, S5360, S5370, S5380, S5390, S5391, S5400, S5420, S5510, S5520, S5560, S5570, S5600, S5610, S5620, S5082, S5085, S5090, S5095, S7720, S7780, S7920, S9021, S9031, S9041, S9051, S9111, S9112, S9121, S9151, S9152, S9161, S9171, S9181, S9182, S9185, S9186, S9311, S9321, S9371, S9511, S9512, S9521, S9522, S9531, S9551, S9552, S9711, S9712, S9721, S9731, S9732, S9741, S9751, S9781, S9911, S9981, S9988, S42, S5290, S5571, S725, S7310, S7311, S7312, S7320, S7330, S7370, S738, S7510, S7520, S7530, S7540, S7550, S8860, S8880, YS1106, YS1107, YS526, YS527, YS536
- Passer til produkttypen: S7950/18, S7960/17, S7960/18, S7970/17, S7970/19, S7970/26
- Passer til disse typer shavere: S7310, S7311, S7320, S7340, S7350, S7360, S7370, S7371, S7510, S7520, S7521, S7522, S7530, S7550, S7560, S7561, S7710, S7720, S7740, S7780, S7920, S7921, S7980, S8860, S8870, S8880, S8950, S8960, S9031, S9041, S9051, S9090, S9091, S9111, S9112, S9131, S9151, S9161, S9171, S9181, S9185, S9186, S9211, S9311, S9531, S9551, S9552, S9721, S9733, S9741, S9751, S9781, S9911, SP9820, SP9821, SP9860, SP9861, SP9863, SV9700, S5672, S5008, S5010, S5011, S5013, S5015, S5040, S5050, S5051, S5070, S5071, S5072, S5073, S5074, S5075, S5076, S5077, S5078, S5079, S5080, S5081, S5082, S5083, S5085, S5086, S5090, S5091, S5095, S5100, S5110, S5120, S5130, S5140, S5150, S5205, S5210, S5211, S5212, S5213, S5214, S5215, S5216, S5230, S5231, S5240, S5250, S5251, S5252, S5270, S5271, S5272, S5273, S5290, S5310, S5320, S5330, S5340, S5351, S5355, S5360, S5361, S5370, S5380, S5390, S5391, S5395, S5396, S5397, S5400, S5420, S5510, S5520, S5530, S5540, S5550, S5551, S5560, S5570, S5571, S5572, S5580, S5590, S5600, S5610, S5620, S5630, S5640, S5650, S5651, S5660, S5670



Udgivelsesdato
2023-07-30

Version: 4.4.1

EAN: 87 10103 78945 1

© 2023 Koninklijke Philips N.V.
Alle rettigheder forbeholdes.

Specifikationerne kan ændres uden varsel. Varemærker tilhører Koninklijke Philips N.V. eller deres respektive ejere.

www.philips.com