



Philips Espresso Water container

- PicoBaristo, Incanto, EP and SM s.
- Transparent
- Not dishwasher-proof

CP0228

Water tank

Please check specifications for compatible product

This water tank is easily detachable for refilling and cleaning. Compatible with PicoBaristo, Incanto, Philips 3100, Philips 4000, EP Series and SM Series, Philips 5000 Series.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

PHILIPS

Water container

PicoBaristo, Incanto, EP and SM s. Transparent, Not dishwasher-proof

CP0228/01

Specifications

Replaceable part

- Fits product types:: HD8911, HD8914, HD8917
- Fits Coffee Product: EP3559/10
- Fits product type: HD8927, HD8924, HD8915/01, HD8915/09, HD8921/01, HD8921/09, HD8925/01, HD8925/09, EP3550/00, EP3551/00, EP4010/

00, EP4050/00, SM3061/00, EP4051/00, EP3363/10, EP3362/00, EP3363/00, EP3551/10, EP3558/00, EP3559/00, EP5360, EP5361, EP5365, EP5960, EP5961, EP5330, EP5331, EP5333, EP5334, EP5335, EP5930, EP5934

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2022-12-28

Version: 6.6.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com