

Philips Whisk (1 pcs)

CP9581

to replace your current whisk

Single whisk accessory for Philips hand blender for whipping cream, mayonnaise, pancake batter and more. Makes your hand blender multifunctional and versatile.

Ease of using Philips spare parts

• Easily renew your product with original Philips parts



Whisk (1 pcs) CP9581/

Specifications

Replaceable part

- Fits product types:: HR1610/00, HR1610/01, HR1611/01, HR1613/03, HR1614/01, HR1615/00, HR1615/90, HR1615/91, HR1617/00, HR1617/01, HR1617/03, HR1617/90, HR1619/00
- Fits product types:: HR1600/00, HR1600/01, HR1600/09, HR1601/00, HR1601/19, HR1602/00, HR1602/01, HR1603/00, HR1604/00, HR1604/01,

HR1604/03, HR1604/09, HR1604/90, HR1605/00, HR1605/01, HR1606/00, HR1607/00, HR1608/00, HR1608/03, HR1609/00, HR1609/03, HR1621/00, HR1621/05, HR1623/00, HR1623/04, HR1625/00, HR1627/00, HR1627/05, HR1628/00, HR1633/80, HR1634/80, HR1635/80, HR1636/80, HR1636/81, HR1637/80, HR1638/90, HR1639/90

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2023-07-13

Version: 6.6.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 87 10103 71868 0

www.philips.com