



Philips
Steam floor cleaner

1500 W

Extra flat nozzle
3 microfiber pads
Adjustable steam

FC7028/61

Truly clean floors with the power of steam

Triangular, flat nozzle for best cleaning results

Truly clean floors with the power of steam. SteamCleaner Active removes dust and dirt for hygienic cleaning results on all hard floors. Its triangular extra flat nozzle reach even in hard to reach places like corners or alongside plinths.

Hygienic cleaning results

- 1300W for powerful steam and fast heat up
- Steam kills up to 99.9% of bacteria and germs
- Steam dissolves dirt, dust and stains

100% chemical free cleaning

- 100% chemical free cleaning
- No detergent needed, no residues left on surfaces
- Suitable for tap water

Adjustable steam for all floors

- For all floors*
- Right amount of steams for different floors

Easy to use and efficient

- 3 Microfiber pads included
- Self standing
- Steam function stops when you pause

PHILIPS

Highlights

Remove dirt easily

Dust and dirt is easily removed by SteamCleaner Active as steam dissolves and the microfiber pad lifts and traps dirt.

1300 W for powerful steam



1300 W for a fast heat-up time. SteamCleaner Active is ready to use in less than 30 sec. The LED indication light turns from white to blue when Steam Plus is ready to steam.

Steam kills bacteria and germs



Enjoy the most hygienic steam cleaning results with Philips SteamCleaner Active. Philips SteamCleaner Active kills up to 99.9% of germs and bacteria. Sanitize all floors without chemicals and only the use of water.

100% chemical free cleaning



SteamCleaner Active works with water only. It does not leave any kind of chemical residues on your floor.

Suitable for tap water



SteamCleaner Active is specially developed to clean using tap water. Its Active Calc Filter decalcifies water automatically. We advise to replace the Active Calc Filter at least every 6 months to prevent calcification and enjoy great performance over lifetime.

No detergent needed




No detergent needed, no residues left on surfaces

Adjustable steam settings

With the adjustable steam setting SteamCleaner Active always releases the right amount of steam for the perfect clean, for all sealed floors, including hardwood and laminate.

For all floors*



For all floors*

Washable microfiber pads



3 washable and durable microfiber pads are included. The soft microfiber material gently loosens, lifts, and absorbs dust and dirt. Removing dirt effectively and gently. The microfiber pads are machine-washable and easy to attach and remove.

Specifications

Weight and dimensions

- Dimensions microfiber pad: 27x11 cm
- Dimensions nozzle: 210 x 230 cm
- Weight (kg): <3 kg

Performance

- Input power (IEC): 1300 W
- Input power (max): 1500 W

Design

- Color: Sparkle Blue

Usability

- Cord length: 6 m
- Removable stick assembly: Stick in / Stick Out

- Stand by mode: Auto steam shut-off
- Cord storage: On stick

Nozzles and accessories

- Accessories included: 3 pads and 1 carpet glider
- Cleaning: Washable microfiber pad
- Steam nozzle: Carpet glider

Steam Management

- Heating-up time: <30 s
- Steam temp. at nozzle: >100 °C
- Runtime (steaming): 15 to 25 minute(s)
- Steam capacity: Δ 13 Δ o 25 g/min
- Watertank size: 450 ml
- Active calc filter



Issue date 2023-04-14

Version: 1.1.1

EAN: 87 10103 66485 7

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* For all hard floor types, including sealed wooden floors. For lacquered wooden floors, first try on a non-visible spot before using. Do not use on oiled wooden floors