



Basket for the tea or teabags in your Teamaker

Check compatibility data

Did you know that green tea needs to be prepared differently from herbal tea? Your Teamaker takes care of it all. The detachable filter basket can be used to put the tea or teabags in.

Ease of using Philips spare parts

Easily renew your product with original Philips parts





Replaceable part • For kitchen appliance model:: HD7311/60,

HD7310/60

Highlights

Easy replacement of product parts From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2023-02-11

© 2023 Koninklijke Philips N.V. All Rights reserved.

Version: 4.4.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 08 71010 35650 86 www.philips.com