Philips Pan for bread maker





Pan for kneading dough and baking bread

Bread pan suitable for product week code >&= 1208

If the pan of your bread maker is worn or damaged, replace it with this original spare part from Philips and enjoy your freshly baked bread in the morning again.

Ease of using Philips spare parts

Easily renew your product with original Philips parts



Pan for bread maker

Specifications

Replaceable part
• Fits product type:: HD9020/40

CP9221/01

Highlights

Easy replacement of product parts From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2023-02-11

© 2023 Koninklijke Philips N.V. All Rights reserved.

Version: 6.6.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 08 71010 36103 11 www.philips.com