



Philips Rechargeable Stick
Accessory
Microfiber Pads

Microfiber pads

XV1700/01

Shiny, cleaner floors with the power of water

Microfiber pads for optimal wetness control

Microfiber pads to effectively remove dirt and stains. Compatible with all of the following Philips Cordless Vacuum Cleaners with Aqua function, starting with: FC61, FC64, FC67, FC68, FC69, XC80, XC81, XC83.

Philips Original accessories

- 2 gentle microfiber pads for delicate floors
- 2 regular microfiber pads
- Replace every 6 months
- Washable and reusable pads

PHILIPS

Specifications

General specifications


- Suitable for: FC61, FC64, FC67, FC68, FC69,

XC80, XC81, XC83

XV1700/01

Highlights

2 gentle microfiber pads



The soft microfiber material gently loosens, lifts, and absorbs dust and dirt. Particularly designed to clean delicate surfaces, such as wooden surfaces. Removing dirt and stains effectively and thoroughly

2 regular microfiber pads



The microfiber material loosens, lifts, and absorbs dust and dirt. Removing dirt and stains effectively and thoroughly.

Replace every 6 months



Replace every 6 months to maintain an optimal cleaning performance of your appliance.

Washable and reusable pads

The microfiber pads are machine-washable and easy to attach and remove



Issue date 2023-07-23

Version: 3.3.1

EAN: 87 10103 92432 6

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com