

The image shows the front cover of a Philips television's quick start guide. The cover is primarily white with a blue curved design element at the bottom. The Philips logo is prominently displayed in blue at the top. Below it, the word 'Television' is written in a large, white, sans-serif font on a blue background. At the very bottom, 'Quick Start Guide' is written in a smaller, white, sans-serif font on a blue background.

Quick Start Guide






























Diagram A illustrates the preparation of the box and the mounting rails. A 3D perspective view of the box is shown with an arrow indicating the top flaps are to be opened. To the right, two long, thin mounting rails are shown, each with a bracket attached to its end. Below the rails, a single screw is shown with the text "x4", indicating that four screws are required for this step.



A diagram illustrating a 180-degree rotation. A vertical rod is shown in its initial position. A curved arrow indicates a rotation of 180 degrees, resulting in a second rod shown in a horizontal position, representing a half-turn.





English Read the safety instructions.
Български Прочетете инструкциите за безопасност.
Čeština Přečtěte si bezpečnostní pokyny.
Hrvatski Pročitajte sigurnosne upute.
Dansk Læs sikkerhedsforskrifterne.
Deutsch Lesen Sie die Sicherheitshinweise.
Ελληνικά Διαβάστε τις οδηγίες ασφαλείας.
Eesti Lugege ohutusõudeid.
Español Lea las instrucciones de seguridad.

Français Lisez les consignes de sécurité.
Italiano Leggere le istruzioni di sicurezza.
Қазақша Қорғаныстық нұсқаулар.
Latviešu Izlasiet drošības norādījumus.
Lietuvių Perskaitykite saugos instrukcijas.
Magyar Olvassa el a biztonsági utasításokat.
Nederlands Lees de veiligheidsvoorschriften.
Norsk Les sikkerhetsforskriftene.
Polski Zapoznaj się z instrukcjami bezpieczeństwa.


Português Leia as instruções de segurança.
Română Citiți instrucțiunile de siguranță.
Русский Читайте инструкции по технике безопасности.
Srpski Pročitajte bezbednosna uputstva.
Slovenščina Preberite varnostna navodila.
Slovenský Prečítajte si bezpečnostné pokyny.
Suomi Lue turvaohjeet.
Svenska Läs säkerhetsinstruktionerna.
ภาษาไทย โปรดอ่านคำแนะนำด้านความปลอดภัย

Türkçe Güvenlik talimatlarını okuyun.
Українська Читайте інструкції з техніки безпеки.
العربية قراءة تعليمات السلامة.
עברית קראו את הוראות הבטיחות

Register your product and get support at www.philips.com/TVsupport

QR code for RC Instructions

QR code for TV software upgrade for Smart TV- (From Internet)



Help

Warning icons: No fire, No smoking, No open flames, No alcohol, No sharp objects, No liquids.

Philips logo

All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips shield emblem are trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V. This product has been manufactured by and is sold under the responsibility of TP Vision Europe B.V. and TP Vision Europe B.V. is the warrantor in relation to this product. 20210: TP Vision Europe B.V. All rights reserved. www.philips.com/welcome