

Register your product and get support at

www.philips.com/welcome



32PFL3404/77

32PFL3404/78

42PFL3604/77

42PFL3604/78






32PFL3414/77

42PFL3614/77






Quick

Start


PHILIPS





1










2









3








HDMI	
	
YPbPr & AUDIO L/R	
	
AUDIO L/R & VIDEO IN	
	









Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2009 © Koninklijke Philips Electronics N.V. All rights reserved.

