








75PUD6754/77
75PUD6754/55


Guía Rápida




A




1




A




B




2




3




4




5




6




7




8



9



10




English Read the safety instructions.
Español Lea la información de seguridad.




Registre su producto y obtenga asistencia en www.philips.com/TVsupport




B




VESA (x, y)
75" 600x400mm M8 189 cm








1



2



3



All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips' shield emblem are trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V. 2019© TP Vision Europe B.V. All rights reserved. philips.com