







70PUD7625/43
70PUD7625/44
Guía Rápida







A

1

2

3







4

5

6

7





English



Read the safety instructions.

Español

Lea la información de seguridad.







Registre su producto y obtenga asistencia en www.philips.com/TVsupport






VESA (x, y)

70" 300x300mm M8 178 cm



2x
AAA
1.5V



All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips' shield emblem are trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V. 2020© TP Vision Europe B.V. All rights reserved. philips.com