





PHILIPS

50PUT6654/57
58PUT6654/57


Guía Rápida




x4




A




B




A



1




2




3

50"




58"




4


50"




58"




5



6



7







English
Español

Read the safety instructions.
Lea la información de seguridad.








Registre su producto y obtenga asistencia en
www.philips.com/TVsupport



VESA (x, y)

50" 200x200mm M6 126 cm
58" 300x200mm M6 146 cm



All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips' shield emblem are trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V. 2019© TP Vision Europe B.V. All rights reserved. philips.com