







LOCATION OF TV POWER SOCKET



LOCATION OF TV ANTENNA SOCKET




CABLE MANAGEMENT




3139 125 39001




DVD PLAYER






DVD RECORDER




VIDEO PLAYER




VIDEO RECORDER





FM RADIO





SATELLITE / CABLE BOX



HIGH-DEFINITION (HD) EQUIPMENT



COMPUTER



GAME / CAMERA / HEADPHONES

