






PHILIPS


大型顯示器

快速使用指南




8516 / 8526 / 8576 系列






A




70"




75"




1






2




L




75"




3





VESA (x, y)






溫馨提示：
壁掛安裝時，請先將機器壁掛鎖附位置的螺絲(已安裝)取出，此螺絲非標準壁掛螺絲，請勿使用。

2

70" 300x300mm M8 (L: 12mm~25mm) 177 cm


75" 300x300mm M8 (L: 12mm~25mm) 189 cm




設備名稱：Philips LED背光源智慧型顯示器
型號(型式)：70PUH8516/96, 70PUH8576/96, 75PUH8516/96, 75PUH8576/96

單元	限用物質及其化學符號					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr ⁶⁺)	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
塑料外框	○	○	○	○	○	○
後殼	○	○	○	○	○	○
液晶面板	-	○	○	○	○	○
電路板組件	-	○	○	○	○	○
底座	○	○	○	○	○	○
電源線	-	○	○	○	○	○
其他線材	-	○	○	○	○	○
遙控器	-	○	○	○	○	○
喇叭	-	○	○	○	○	○

備考1. "○" 係指該項限用物質之百分比含量未超出百分比含量基準值。
備考2. "-" 係指該項限用物質為排除項目。



繁體中文 請閱讀安全說明。



此機種無附上紙本使用手冊，請使用以下網址輸入機種型號搜尋後自行下載。
*使用手冊包含限用物質標示說明。
www.philips.com/TVsupport

