











6784 series
Quick Start Guide




A1
55"


1




2




A




B





3



4





5




A2
65"


1




2




3




4




5




B




VESA (x, y)

55" 300x200mm M6  139 cm65" 400x200mm M6  164 cm


1



2

2x
AAA
1.5V

3

**English** Read the safety instructions.**Bahasa Malaysia** Baca arahan Keselamatan.**Bahasa Indonesia** Baca petunjuk keselamatan.**Deutsch** Lesen Sie die Sicherheitshinweise.**Français** Lisez les consignes de sécurité.**Português** Leia as instruções de segurança.**ภาษาไทย** โปรดอ่านคำแนะนำด้านความปลอดภัย**Tiếng Việt** Hãy đọc chỉ dẫn an toàn.**简体中文** 请阅读安全说明。**العربية** قراءة تعليمات السلامة.Register your product and get support at
www.philips.com/TVsupport