

Home theater system
Système de cinéma à domicile
Sistema Home theatre

Component Video Input (CVI)
Entrée vidéo composant
Entrada de vídeo componente

OR / OU / O

HDMI

TV

Source List

Game/Camera/Headphones
Jeux/Caméra/Casque
Juegos/Cámara/Auriculares

Composite Audio / Video (SIDE)
Audio/Video composite (LATERAL)
Audio/Vídeo compuesto (LADO)

OR / OU / O

S-VIDEO (Y/C)
S-VÍDEO
S-VÍDEO

TV

Source List

Personal computer
Ordinateur personnel
Computadora personal

VGA

OR / OU / O

HDMI

TV

Source List

External audio system
Système audio externe
Sistema de audio externo

Composite Audio
Audio composite
Audio compuesto

TV

HD devices/HD DVD
Périphériques HD/HD DVD
Dispositivos HD/HD DVD

OR / OU / O

HDMI

TV

Source List

OR / OU / O

HDMI

TV

Source List

OR / OU / O

Headphones
Casque
Auriculares

TV

Source List

Cable management
Gestion des câbles
Manejo del cable

A

B

C

3

Enjoy
Bon divertissement!
Disfrute

Quick Start Guide

Guide de démarrage rapide

Guía de inicio rápida

1 Setup
Configuration
Configuración

2 Connect
Connecter
Conectar

3 Enjoy
Bon divertissement!
Disfrute

M6 (18mm) x 4
M5 (25mm) x 2
R03 / AAA (1.5V) x 2

PHILIPS

www.philips.com

© 2005 Philips Electronics NV. All rights reserved.

Trademarks are the property of Philips Electronics NV or their respective owners.

Scoposystem is a registered trademark of Philips Electronics NV.

SD111HD

1 Setup
Configuration
Configuración

Assemble
Assemblez
Ensamblaje

A x 2

B

C

M6 (18mm) x 4

D

E

F

M5 (25mm) x 2

G

Basic connections
Connexion de base
Conexión básica

Power cord
Cordon d'alimentation
Cable de suministro eléctrico

Antenna / Cable
Antenna/Cable

On / Sous tension
Si

Standby
En marche
Standby

Off / Hors tension
No

Locating the TV connectors
Emplacement des prises du téléviseur
Ubicación de los conectores del TV

2 Connect
Connecter
Conecte

Cable box or set top box
Boîtier décodeur
Caja de cable o caja superior de ajuste

OR / OU / O

OR / OU / O

OR / OU / O

OR / OU / O

DVD player or recorder
Lecteur ou enregistreur de DVD
Reproductor o grabador de DVD

OR / OU / O

OR / OU / O

VCR
Magnétoscope
VCR

OR / OU / O

OR / OU / O