



Designed with
GEORG JENSEN

Register your product and get support at
www.philips.com/TVsupport

Quick Start Guide



B

!

20 cm

20 cm

VESA (x, y)

55" 300x200mm M6 (L: 10mm-16mm)

139 cm

VESA

TV

x

y

L

x4

1

2x AAA LR03 1.5V

2

3

4

5

Click

6

1

2x AAA LR03 1.5V

2

3

4

Click

1

<= 1m

3 SEC

PAIR

2

OK!

Google Assistant

VOICE

English

Български

Čeština

Hrvatski

Dansk

Deutsch

Ελληνικά

Eesti

Español

Read the safety instructions.
Прочетете инструкциите за безопасност.
Přečtěte si bezpečnostní pokyny.
Pročitajte sigurnosne upute.
Läs säkerhetsföreskrifterna.
Lesen Sie die Sicherheitshinweise.
Διαβάστε τις οδηγίες ασφαλείας.
Lugege ohutusnõudeid.
Lea las instrucciones de seguridad.

Français

Italiano

Kazакша

Latviešu

Lietuvių

Magyar

Nederlands

Norsk

Polski

Lisez les consignes de sécurité.
Leggere le istruzioni di sicurezza.
Қорғаныстық нұсқаулар.
Izlasiet drošības norādījumus.
Perskaitykite saugos instrukcijas.
Olvassa el a biztonsági utasításokat.
Lees de veiligheidsvoorschriften.
Les sikkerhetsforskriftene.
Zapoznaj się z instrukcjami bezpieczeństwa.

Português

Română

Русский

Srpski

Slovenščina

Slovensky

Suomi

Svenska

தமிழ்

Leia as instruções de segurança.
Citiți instrucțiunile de siguranță.
Читайте инструкции по технике безопасности.
Pročitajte bezbednosna uputstva.
Preberite varnostna navodila.
Prečítajte si bezpečnostné pokyny.
Lue turvaohjeet.
Läs säkerhetsinstruktionerna.
โปรดอ่านคำแนะนำด้านความปลอดภัย

Türkçe

Українська

العربية

Güvenlik talimatlarını okuyun.
Читайте інструкції з техніки безпеки.
قراءة تعليمات السلامة

עברית

קראו את הוראות הבטיחות

www.philips.com/TVsupport

PHILIPS

COMMON INTERFACE

USB

HDMI 1 MHL

CAM

HDD REC

POWER (EU)

POWER (UK)

NETWORK

DIGITAL AUDIO OUT

SAT1 (EU)

SAT1 SAT2 (EU)

ANTENNA

Y Pb Pr L/R

HDMI ARC

HDMI

INTERNET

TOSLINK

SATELLITE COAXIAL

SATELLITE COAXIAL

COAXIAL

Y Pb Pr

HDMI

Help