



What's in the box

包装内的物品清单




Base
底座架

x 3


Screws
螺丝钉



Power cord
电源线



Remote Control & Batteries
遥控器和电池




User Manual
用户手册



Warranty card
保修卡

What else you'll need 您所需要的物品




AC



X1



X3



X1


5

Remove the cushion. Put the TV face down on a soft and smooth surface, such as newspaper or PE bag.

取下小泡沫垫。将电视机面朝下放在柔软且平滑的表面上，如报纸或珍珠袋。



X1



6

Follow the step to screw the base.
(For wall mounting, please turn over the page)
按照下列步骤拧紧底座架。
(墙式安装，请翻至后面。)





X1



X3




X1





7

Switch the TV on.
打开电视机。



8

Place the batteries in the remote control.
将电池放入遥控器中。



1

Open the box.
打开包装盒。

2


Remove accessories from the box.
从包装盒中取出配件。

3



Remove the base.
取出底座架。

4

Remove the TV from the box.
从包装盒中取出电视机。




Rear and side connectors. 后面和侧面连接插头



Auto Store 自动搜寻

Immediately after unpacking and plugging in your new television, run the auto store function to set up the TV for the antenna or cable channels available in your area. If you do not run the auto store function to set up the channels, your television may not operate properly. (See User Manual page 10.)

在打开包装并连通这台新电视的电源后，立即进行自动搜寻功能设置电视，使其记忆您所在的地区可用的天线或有线电视频道。如果不进行自动搜寻功能设置频道，电视可能无法正常工作。(参见用户手册第10页。)




Welcome 欢迎

Read me 阅读我

Wall mounting 墙式安装

What else you'll need 您所需要的物品






When installing the LCDTV on the wall, please consult a professional technician for proper installing. The manufacture accepts no liability for installations not performed by professional technician.

将液晶电视挂在墙上时，请咨询专业技术人员以了解正确的安装方式。制造商对于非专业人士进行的安装不承担任何责任。


The manufacture accepts no liability for damage of improper installation. Any question, please consult your dealer or service center.

生产商对不当安装所造成的损失将不负任何责任。如有疑问，请与销售商或服务中心联系。

Follow these steps to remove the base and the base column.
按照下列步骤取下底座架和底座支架。



Wall mounting holes.
墙式安装孔。



PA17A026813 1A



Printed in China

www.philips.com

Specifications are subject to change without notice