



In-between Clean

The unique brush head design helps dislodge plaque and food particles in-between teeth.

A brush head that fits multiple handles

• Snap-on brush head

Designed to optimize performance

• Reminder bristles ensure you are getting an effective clean

Thorough clean feeling in your mouth

• Brush head design maximizes sonic motion

Delivers a better clean in-between

• Hydroguides help dislodge plaque and food particles

Highlights

Snap-on brush head



Easy brush head placement and handle cleaning

Hydroguides

HydroGuides works with our patented sonic technology to direct toothpaste and water between teeth to help you clean those tight spaces. While it doesn't replace flossing, it can help give you a better clean between teeth.

Maximize cleaning performance



Thoughtful design and precision engineering ensure that when this Philips Sonicare replacement brushes are combined with the sonic motion and flexible brushing modes, you get a thorough clean.

Reminder bristles



Reminder bristles let's you know when to replace the brush head. After three months of normal use bristles exhibit fatigue, and brush heads are less effective. Replace your brush heads every 3 months.

Specifications

Technical specifications

Operating time: For optimal results, a new brush head is recommended every three months.

Items Included

Hygienic travel cap: 1 pcs

© 2023 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2023-03-03

