

Register your product and get support at
www.philips.com/welcome

3500 series

Quick start guide

PHILIPS



English Before using your product, read all accompanying safety information

Français Avant d'utiliser votre produit, lisez l'intégralité des consignes de sécurité jointes.

ภาษาไทย ก่อนการใช้ผลิตภัณฑ์ โปรดอ่านข้อมูลความปลอดภัยทั้งหมดที่มาพร้อมผลิตภัณฑ์

Tiếng Việt Trước khi sử dụng sản phẩm, hãy đọc tất cả thông tin an toàn kèm theo


简体中文 使用产品前，请阅读所有随附的安全信息。

繁体中文 使用您的產品前，請先閱讀所有附隨的安全資訊。




العربية بل استخدام المنتج الخاص بكم، يرجى قراءة كافة معلومات الأمان المرفقة مع المنتج



English What's in the box
Français Contenu de l'emballage
ภาษาไทย สิ่งที่อยู่ในบรรจุภัณฑ์
Tiếng Việt Có gì trong hộp
简体中文 包装盒内物品
繁体中文 包裝盒內容
العربية محتويات العبوة



M4 x 12mm



(/56)

1

English Mount the stand
Français Montage du support

ภาษาไทย ยึดขาตั้ง


Tiếng Việt Gắn chân đế

简体中文 安装支架



繁体中文 安裝立架

العربية تثبيت الحامل

1



2



2

English Connect
Français Connexion


ภาษาไทย เชื่อมต่อ


Tiếng Việt Kết nối





简体中文 连接



繁体中文 連接

العربية التوصيل














3

English Manage cables
 Français Gestion des câbles
 ภาษาไทย จัดเก็บสายสัญญาณ
 Tiếng Việt Quản lý cáp
 简体中文 布线
 繁体中文 管理纜線
 العربية التعامل مع الكابلات




4


English Insert batteries
 Français Insertion des piles
 ภาษาไทย ใส่แบตเตอรี่
 Tiếng Việt Quản lý cáp
 简体中文 插入电池
 繁体中文 插入電池
 العربية إدخال البطاريات



5

- English** Select your language and follow the onscreen instructions
- Français** Sélectionnez votre langue et suivez les instructions à l'écran
- ภาษาไทย** เลือกภาษาของคุณและทำตามคำแนะนำบนหน้าจอ
- Tiếng Việt** Chọn ngôn ngữ và thực hiện theo hướng dẫn trên màn hình.
- 简体中文** 选择您的语言并按照屏幕说明操作。
- 繁体中文** 選擇語言並按照螢幕指示。
- العربية** اختر لغتك و اتبع التعليمات الظاهرة على الشاشة





English **Play buttons**
Control playback of media files

Français **Touches de lecture**
Contrôler la lecture des fichiers multimédias


ภาษาไทย **ปุ่มเล่น**
ควบคุมการเล่นสื่อ

Tiếng Việt **Nút phát**
Kiểm soát phát lại các tập tin phương tiện

简体中文 **播放按钮**
控制媒体文件的播放

繁体中文 **播放按钮**
控制媒體檔案播放

العربية **أزرار التشغيل**
للتحكم في تشغيل ملفات الوسائط



English **TV**
Switch source to watch TV

Français **TV**
Changer de source pour regarder la télévision


ภาษาไทย **ทีวี**
เปลี่ยนแหล่งข้อมูลเพื่อดูทีวี

Tiếng Việt **TV**
Chuyển nguồn để xem TV

简体中文 **电视**
切换信号源以观看电视

繁体中文 **電視**
切換來源至觀賞電視

العربية **التلفزيون**
لتبديل المصدر إلى وضع مشاهدة التلفزيون



English **Source**
Access a connected device

Français **Source**
Accéder à un périphérique connecté


ภาษาไทย **แหล่ง**
เข้าดูอุปกรณ์ที่เชื่อมต่อ

Tiếng Việt **Nguồn**
Truy cập các thiết bị được kết nối

简体中文 **信号源**
访问连接的设备

繁体中文 **來源**
存取連接的裝置

العربية **المصدر**
للوصول إلى جهاز متصل



English **Format**
Access a connected device

Français **Format**
Changer de format d'image


ภาษาไทย **รูปแบบ**
เปลี่ยนรูปแบบไฟล์ภาพ

Tiếng Việt **Định dạng**
Thay đổi định dạng hình ảnh

简体中文 **格式**
更改图片格式


繁体中文 **格式**
變更畫面格式

العربية **التنسيق**
لتغيير تنسيق الصورة




English Home
Access the Home menu
Français Accueil
Accéder au menu Accueil
ภาษาไทย หน้าแรก
เข้าใช้เมนูหน้าแรก

Tiếng Việt Menu chính
Kiểm soát phát lại các tập tin
phương tiện
简体中文 主页
访问主页菜单
繁體中文 首頁
存取首頁選單
القائمة الرئيسية العربية
للوصول إلى القائمة الرئيسية




English List
Access the TV channel list
Français List
Accéder à la liste des chaînes de
télévision
ภาษาไทย รายการ
เข้าดูรายการช่องทีวี

Tiếng Việt Danh sách
Truy cập danh sách kênh TV
简体中文 列表
访问电视频道列表
繁體中文 清單
存取電視頻道清單
القائمة العربية
للوصول إلى قائمة القنوات التلفزيونية




English Adjust
Adjust TV settings
Français Adjust
Régler les paramètres du
téléviseur
ภาษาไทย ปรับ
ปรับการตั้งค่าทีวี

Tiếng Việt Điều chỉnh
Điều chỉnh cài đặt TV
简体中文 调整
调整电视机设置
繁體中文 調整
調整電視設定
الضبط العربية
لضبط إعدادات التلفزيون



English Options
Access currently available
options
Français Options
Accéder aux options disponibles
ภาษาไทย ตัวเลือก
เข้าใช้ตัวเลือกที่มีในปัจจุบัน

Tiếng Việt Tùy chọn
Truy cập các tùy chọn hiện
có sẵn
简体中文 选项
访问当前可用的选项
繁體中文 選項
存取目前可用的選項
الخيارات العربية
للوصول إلى الخيارات المتاحة حالياً



English

Navigation

Navigate through menus and select items

Français

Navigation

Naviguer dans les menus et sélectionner des éléments

ภาษาไทย

สำรวจ

เลื่อนดูเมนูและเลือกรายการ

Tiếng Việt

Điều hướng

Điều hướng qua các menu và chọn mục

简体中文

导航

在菜单间导航并选择项目

繁体中文

瀏覽

瀏覽選單和選取的項目

العربية

للتنقل في القوائم واختيار العناصر



All registered and unregistered trademarks are the property of their respective owners.

Specifications are subject to change without notice.

Philips and the Philips' shield emblem are registered trademarks of Koninklijke Philips Electronics N.V. and are used under license from Koninklijke Philips Electronics N.V.

2012 © TPVision Netherlands B.V. All rights reserved.

www.philips.com

