




Cable receiver, HD cable receiver




Video cassette recorder




DVD recorder




DVD player, Home theater system, Blu-ray Disc player, HD game console



External audio device



HD camcorder, Headphones, game console, camcorder, PC




Register your product and get support at:
www.philips.com/welcome

Quick Start Guide


Installation




What's in the box




Remove the swivel lock




Connect the mains* and antenna




Setup Ambilight



Use the remote control



Install for the first time



Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners.
2008 © Koninklijke Philips Electronics N.V. All rights reserved.
www.philips.com



3139 125 0000x

Printed in XXX