






Register your product and get support at www.philips.com/TVsupport

Quick Start Guide





English Read the safety instructions.
Български Прочетете инструкциите за безопасност.
Čeština Přečtěte si bezpečnostní pokyny.
Hrvatski Pročitajte sigurnosne upute.
Dansk Læs sikkerhedsforskrifterne.
Deutsch Lesen Sie die Sicherheitshinweise.
Ελληνικά Διαβάστε τις οδηγίες ασφαλείας.
Eesti Lugege ohutusõudeid.
Español Lea las instrucciones de seguridad.

Français Lisez les consignes de sécurité.
Italiano Leggere le istruzioni di sicurezza.
Kazaksha Қорғаныстық нұсқаулар.
Latviešu Izlasiet drošības norādījumus.
Lietuvių Perskaitykite saugos instrukcijas.
Magyar Olvassa el a biztonsági utasításokat.
Nederlands Lees de veiligheidsvoorschriften.
Norsk Les sikkerhetsforskriftene.
Polski Zapoznaj się z instrukcjami bezpieczeństwa.

Português Leia as instruções de segurança.
Română Citiți instrucțiunile de siguranță.
Русский Читайте инструкции по технике безопасности.
Srpski Pročitajte bezbednosna uputstva.
Slovenščina Preberite varnostna navodila.
Slovensky Prečítajte si bezpečnostné pokyny.
Suomi Lue turvaohjeet.
Svenska Läs säkerhetsinstruktionerna.
தமிழ் பார்க்கவும்.

Türkçe Güvenlik talimatlarını okuyun.
Українська Читайте інструкції з техніки безпеки.
العربية قراءة تعليمات السلامة.
עברית קראו את הוראות הבטיחות

www.philips.com/TVsupport

QR code linking to Philips TV support page.

B

20 cm

20 cm

VESA (x, y)
65" 300x300mm M6 (L: 10mm~15mm)
164 cm

POWER (EU) POWER (UK)

COMMON INTERFACE

USB 1 5.0V==500mA

USB 2 5.0V==900mA

HDMI ARC

NETWORK

SAT1 (EU)

SAT1 SAT2 (EU)

ANTENNA

DIGITAL AUDIO OUT

Y Pb Pr L/R

HDMI ARC

TV software upgrade for Smart TV- (From Internet)

RC Instructions

DualTuner

Wi-Fi CERTIFIED

Internet

SATELLITE COAXIAL

COAXIAL

TOSLINK

Y Pb Pr

HDMI

Help