

PHILIPS

Botella Térmica

AWP2662

**Disfruta hidratándote
de forma comoda e higiénica**



**Manual de Usuario
User Manual**

PT

- ① Tapa
- ② Boquilla
- ③ Boton de apertura
- ④ Base tapa
- ⑤ Conducto interno
- ⑥ Botella
- ⑦ Bucle de transporte

EN

- ① Cap
- ② Mouthpiece
- ③ Pop-up button
- ④ Lid
- ⑤ Straw
- ⑥ Bottle
- ⑦ Carry loop



Especificaciones


Capacidad	550mL
Dimensión	75*246mm
Caliente	12hr
Frío	24hr

Precaución

- No llene en exceso su termo.
- No usar dentro de microondas.
- Mantenga el termo fuera del alcance de los niños cuando esté lleno de bebidas calientes.
- El termo diaria se puede llenar con agua de 0°C a 50°C. Cuando se llene con agua caliente, tenga cuidado, en caso de que salpique al abrir la tapa.

Instrucciones de uso y limpieza

1. Desenrosque la tapa y retire el conducto interno, limpie todos los componentes con un detergente suave a mano o en el lavavajillas (máx 50°C).
2. Lave su termo con detergente suave y enjuague antes de usar. Para eliminar las manchas difíciles, use dos cucharaditas de bicarbonato de sodio y agua tibia. Deje reposar durante una hora antes de enjuagar bien.
3. Cuando limpie el producto, no use lejía, diluyente, bencina, depurador de metales, abrasivos o limpiadores. El producto puede estar dañado. Limpiar suavemente con jabón suave.
4. Los productos de acero inoxidable a menudo se dejan sumergidos en agua durante mucho tiempo, no sumerja la botella en agua durante mucho tiempo. El agua puede entrar por las grietas y causar oxidación o aislamiento o enfriamiento deficientes.



5. Al limpiarla, para un uso higiénico, lávelo lo antes posible después de su uso y no lo hierva en agua hirviendo ya que el calor puede causar la deformación del producto.
6. Le recomendamos que precaliente/preenfríe su botella antes de usarla. Llene la botella con agua fría y déjela reposar durante 5 minutos, luego vacíela y vuelva a llenarla con sus bebidas favoritas incluso con hielo.
7. Para su salud, consuma bebidas perecederas como la leche rápidamente y limpie su botella de inmediato. No agregue alimentos salados como sopas.
8. Para evitar derrames y fugas, asegúrese de que la tapa esté bien cerrada.
9. Para evitar la erupción repentina de líquido presurizado, no use su botella para refrescos o bebidas carbonatadas. No use hielo seco, refrescos o bebidas carbonatadas en la botella para evitar lesiones debido al chorro repentino de líquido presurizado.

10. Para prolongar la vida útil del producto, evite impactos violentos y caídas, ya que pueden dañar el termo.

Garantía y Servicio

Si necesita información o si tiene algún problema, visite el sitio web de Philips en www.philips.com o comuníquese con el centro de atención al consumidor de su país. Si no hay en su país, diríjase a un distribuidor local.

Specifications


Capacity	550mL
Dimension	75*246mm
Hot	12hr
Cold	24hr

Caution

- Do not overfill your bottle.
- Do not microwave.
- Keep the bottle out of reach of children when filled with hot beverages.
- The Daily insulated bottle can be filled with water of 0°C to 50°C. When filled with hot water, please be careful, in case it splashes out when you open the cap.

Use and cleaning instruction

1. Unscrew the lid and remove the straw, clean all the components with a mild detergent by hand or in the dishwasher (max 50°C).
2. Please wash your bottle with mild detergent and rinse before use. To remove stubborn stains, use two teaspoons baking soda and warm water. Let stand for one hour before rinsing thoroughly.
3. When cleaning the product, do not use bleach, thinner, benzene, metal scrubber, abrasives or cleanser. The product may be damaged. Gently clean using a mild dishwashing detergent.
4. Stainless steel products are often left immersed in water for a long time, do not immerse the body in water for a long period of time. Water may enter through cracks and cause rust or poor insulation or cooling.
5. When cleaning, for clean use, wash it as soon as possible after use and do not boil it in boiling water as heat may cause



deformation of the product.

6. We recommend you pre-heat/pre-cool your bottle before use. Fill bottle with cold water and let stand for 5 minutes, then empty it and refill with your favorite drinks even with ice.
7. For your health, please consume perishable drinks like milk quickly and clean your bottle promptly. Do not add salty foods such as soups.
8. To prevent spills and leakage, make sure your lid is fastened properly.
9. To avoid sudden eruption of pressurized liquid, do not use your bottle for sodas or carbonated drinks. Do not use dry ice, soda or carbonated beverages in the bottle to avoid injury due to the sudden squirt of pressurized liquid.
10. For longer product life, please avoid violent impacts and drops, as they may damage the bottle.

Guarantee & Service

If you need information or if you have any problems, please visit the Philips website at www.philips.com or contact the consumer care center in your country. If there is no consumer care center in your country, go to a local dealer.



Specifications are subject to change without notice
www.philips.com/water

© 2023 AquaShield
All rights reserved.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of Hong Kong AquaShield Health Technology Company Limited and Hong Kong AquaShield Health Technology Company Limited is the warrantor in relation to this product.

Rev A MAR 23



Gracias por ser parte de las soluciones y ayudar a reducir las basuras de plásticos desechables.

La botella térmica Philips Daily es perfecta para disfrutar del agua cuando estés en camino.

Thank you for being part of the solutions, and helping to reduce single-use plastic waste.

Philips Daily Insulated bottle is perfect for enjoying water when you are on-the-go.