



Philips
Sensitive Skin Cleansing
Brush

Replace every 3 months

For daily use
Normal to sensitive skin
Easy to replace

Replacement Brush Head for Sensitive Skin

For clean and soft skin

Replacement Brush Head specifically designed for Sensitive Skin care. For use only with Philips PureRadiance facial cleansing brush.

Easy to maneuver to focus on hard-to-reach areas

- Perfect size and shape to easily reach all face areas

Easy to replace

- For optimal results, replace the brush every three months
- Easy to fit and compatible only with Philips PureRadiance

Developed for sensitive skin types

- Ultra soft bristles for a more effective, gentle cleaning
- Perfectly designed for optimal hygiene



SC5991/30

PHILIPS

Sensitive Skin Cleansing Brush

Replace every 3 months For daily use, Normal to sensitive skin, Easy to replace

Specifications

Benefits

- Type of skin: For sensitive skin

Service

- Warranty: 2-year limited warranty

Ease of use

- Compatible with: Philips PureRadiance
- Replacement: Easy snap-on brush head
- Recommended replacement: Every 3 months

SC5991/30

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Long operating time

For optimal results, replace the brush every three months

Brush Bristles

The specially designed filaments are even thinner and softer than those of the normal brush head to deliver an even softer and delicate cleansing experience specific for sensitive skin.

Snap-on brush head

Easy to fit and compatible only with Philips PureRadiance.

Designed for optimal hygiene



The silky soft bristle material of all our VisaPure brush heads is a specially chosen, delicate nylon. This helps to ensure the brush heads are super easy to clean and keep fresh.



Issue date 2024-01-14

Version: 4.0.1

UPC: 0 75020 04264 4

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com