

External display: One-key operations without opening the flip



Volume keys/
Multi-functional
keys for the
external display.
In different modes,
press the keys to
access different
functions.

Turn on the external display

Press either one of the keys to turn on the external display. After a while, the screen is turned off automatically for power-saving.

In the idle mode, the local time is shown on external display. Set the clock time correctly (see the "Get Started" chapter in the User Manual).

In the time of new events



Missed calls

New messages

to-do tasks
in the calendar

When there are
different types of
events, press one of
the keys to navigate
through them.

In the time of an incoming call



When there is an incoming call, the phone number or contact name (if in your phonebook) appears on the external display.



To mute the ringtone, short press either one of the keys.

To reject the call, long press either one of the keys.

During the call

To adjust the volume, press the keys repeatedly.

During music/ radio playback in the background



To search for a song or channel, long press one of the keys.



To adjust the volume, press the keys repeatedly.

When the alarm sounds



To interrupt sounding, short press either one of the keys.

To stop sounding, long press either one of the keys.