




What's in the box

包装内的物品清单




Remote control & Batteries

遥控器及电池



What else you'll need

您所需要的其他物品



1 Remove the Packing belt.

拆除打包带。



2 Open the top cover of the carton.

打开纸箱上盖。

3 Remove the top EPS foam and accessories.

取出上部EPS泡沫及附件。

4 Remove carton buckle.

拆除纸箱扣。

5 Remove the top of the carton.

取出纸箱上盖。



6 Remove the left and right sides of the EPS foam.

取出左右侧EPS泡沫。

7 Remove the whole machine

取出整机

Rear connectors

后面接口

Connect to PC

连接至PC



Wall mounting

墙挂

LCD Display

交互式液晶显示器
75BDL3001T

Quick start guide

快速入门指南

- 1 Installation/安装
- 2 connect/连接性


Register your product and get support at
www.philips.com/welcome

PHILIPS

Wall mounting holes

安装孔位

M8(30+x)
X=thickness of wall mount kit




! M8 (30mm) bolts (not standard) is required when hanging on a wall bracket.

挂到壁挂支架上时，需要M8(30mm)螺栓(不标配)。


Switch the LCD display on.

接通电源



Place the batteries in the remote control.

安装遥控器电池



©2019 Koninklijke Philips N.V. All rights reserved.
Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.
Specifications are subject to change without notice.

HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE

NOTICE: The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.