



尺寸：65*100mm
 平面展开：585*200mm
 材质：70克书写纸
 颜色：单黑印刷/无表面处理
 料号：406-000-00286

正面1

PHILIPS
 User manual
 SPK7384
 Wireless mouse
 User manual




正面2



正面3

Functional Overview



1. Wheel
2. Left-Right button
3. Philips LOGO
4. Non-slip feet
5. ON/OFF switch
6. Wireless receiver

正面4

Package Contents

- 1 x 2.4G wireless mouse
- 1 x Wireless receiver
- 1 x User manual

System Requirement

- Your product works with Windows®, Mac, Chrome OS and Linux®.
- No matter what type of computer you own today or buy tomorrow—you can depend on your product to work like you expect.

Trouble Removal

Guiding Questions

- Make sure the computer meet the minimum system requirement.
- If you can't solve the problem, please try to find solution from Philips website or nearest retailer. Please do not disassemble the product by force.
- If the distance between the keyboard (or mouse) and receive exceed effective range, please reduce the distance for better performance.

Attention

- Please use dry and soft cloth to clean the product.
- Please do not wash the product directly with water.
- Please do not use this product on any reflective surface, transparent surface or uneven surface.


Technical Specifications

Connectivity: 2.4G wireless
 Sensor: Optical sensor
 Number of buttons: 3
 Button lifespan: 3 million
 Effective distance: 10m
 DPI: 1600DPI
 Power supply: 1 x AA battery
 Product size: 100*63*39mm
 Product weight: 65±5g

正面5

Product Environmental Notices

Disposal of Waste Equipment by Users in Private Household in the European Union




This symbol on the product or on its packaging indicates that this product must not be disposed of with your household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact the local city office, the household waste disposal service or the shop where you purchased the product.

PHILIPS Recycling Program

PHILIPS encourages customers to recycle used electronic hardware. PHILIPS original print cartridges, and rechargeable batteries. For more information about recycling programs, go to <http://www.philips.com/a-w/about/sustainability.html>

正面6

PHILIPS



2019 © Top Victory Investments Limited. All rights reserved. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of Top Victory Investments Limited, and Top Victory Investments Limited is the warrantor in relation to this product.

Made in China


Through the following website, you can register your product in order to get support.
www.philips.com/welcome

正面7

PHILIPS
 使用说明书
 SPK7384
 无线鼠标
 使用说明书




正面8



正面9

功能概述



- 1.上下方向滚轮
- 2.左、右键单击按键
- 3.产品丝印LOGO
- 4.耐磨脚垫
- 5.独立电源开关
- 6.无线接收器

背面1

完整套件包括

- 无线鼠标
- 无线接收器
- 使用说明书

系统要求

- Windows10、Windows7、Windows Vista、Windows XP、WIN8、Mac OS
- 1 x USB 接口

故障排除

问题

提示 1.确保将鼠标的 USB 连接器正确插入电脑的 USB 端口。
 2.确保电脑满足最低系统要求。
 3.若有不能解决的问题，请不要自行拆卸，登陆官网寻求解决方法或送就近经销商处理。

注意：
 光电技术可正确的检测鼠标在大多数表面上的运动。不要在任何反射表面、透明金属表面或不平整的表面上使用该鼠标。清洁鼠标请使用干燥、柔软的棉织品等。

技术规格

连接方式：2.4G无线
 传感器：光学传感器
 按键数量：3
 按键寿命：300万次
 有效距离：10m
 分辨率：1600DPI
 电源：一节AA电池
 产品尺寸：100*63*39mm
 产品重量：65±5g


背面2

环境信息

旧产品处理

您的产品使用优质原材料和部件设计制造，可以回收和再利用。

产品上标有“打叉的垃圾箱”符号时，表示该产品符合 European Directive 2002/96/EC 的要求。



请注意了解有关当地电子电气产品分类回收系统的信息。


请按照当地的有关规章条例行动且不要将旧产品与日常家居废物一起丢弃。正确处理旧产品将有助于防止对环境及人类健康造成潜在的负面后果。

注意：

1. 不宜折弯弯曲本产品
2. 不宜在反射或透明表面使用本产品
3. 不宜强行拆卸本产品
4. 不宜将鼠标底部光线直射眼睛
5. 不宜淋雨
6. 不宜暴晒
7. 不宜火烤
8. 不宜直接用水冲洗

背面3

PHILIPS



2019 © Top Victory Investments Limited. 保留所有权利。Philips 和 Philips 盾徽是 Koninklijke Philips N.V. 的注册商标，并经过许可使用。本产品由 Top Victory Investments Limited 或其附属公司或者其授权公司制造和销售。Top Victory Investments Limited 是该产品的相关负责人。

中国制造


通过下面网站，注册您的产品以获取支持
www.philips.com/welcome

背面4

PHILIPS
 使用说明书
 SPK7384
 无线鼠标
 使用说明书




背面5



背面6

功能概述



- 1.上下方向滚轮
- 2.左右键按一下按键
- 3.产品丝印LOGO
- 4.耐磨脚垫
- 5.独立电源开关
- 6.无线接收器

背面7

完整套件包括

- 无线鼠标
- 无线接收器
- 使用说明书

系统要求

- Windows10、Windows7、Windows Vista、Windows XP、WIN8、Mac OS
- 1 x USB 孔

故障排除

问题

提示 1.确保将鼠标的 USB 连接器正确插入电脑的 USB 孔。
 2.确保电脑满足最低系统要求。
 3.若有不能解决的问题，请不要自行拆卸，登入官网寻求解决方法或送就近经销商处理。

注意：
 光电技术可正确的检测鼠标在大多数表面上的运动。不要在任何反射表面、透明金属表面或不平整的表面上使用该鼠标。清洁鼠标请使用干燥、柔软的棉织品等。

技术规格

连接方式：2.4G无线
 传感器：光学传感器
 按键数量：3
 按键寿命：300万次
 有效距离：10m
 分辨率：1600DPI
 电源：一节AA电池
 产品尺寸：100*63*39mm
 产品重量：65±5g


背面8

环境资讯

舊產品處理

您的產品使用優質原材料和零件設計製造，可以回收和再利用。

產品上標有“打叉的垃圾箱”符號時，表示該產品符合 European Directive 2002/96/EC 的要求。



請注意瞭解有關當地電子電器產品分類回收系統的資訊。


請按照當地的有關規章條例行動且不要將舊產品與日常家居廢物一起丟棄。正確處理舊產品將有助於防止對環境及人類健康造成潛在的負面後果。

注意：

1. 不宜折弯弯曲本产品
2. 不宜在反射或透明表面使用本产品
3. 不宜强行拆卸本产品
4. 不宜将鼠标底部光线直射眼睛
5. 不宜淋雨
6. 不宜暴晒
7. 不宜火烤
8. 不宜直接用水冲洗

背面9

PHILIPS



2019 © Top Victory Investments Limited. 保留所有权利。Philips 和 Philips 盾徽是 Koninklijke Philips N.V. 的注册商标，并经过许可使用。本产品由 Top Victory Investments Limited 或其附属公司或者其授权公司制造和销售。Top Victory Investments Limited 是该产品的相关负责人。

中国制造

通过下面的网站，注册您的产品以获取支持
www.philips.com/welcome