




User manual



Function overview of the mouse


- Scroll wheel
 Left and right buttons
- 3. Forward/backward side buttons 4. DPI button
- 5. Low battery indicator
- Wireless receiver
 Optical sensor
 ON/OFF switch
- 9. Battery door

3. Take out the receiver and


4. Plug the receiver into the

Connection Guide

1. Push the battery door away.



2. Pull off the battery insulating film.





2022 © Top Victory Investments Limited . All rights reserved.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Limited , and Top Victory Investments Limited is the warrantor in relation to this product.

Specifications are subject to change without notice

Register your product and get support at:

Packaging contents

- 2 Wireless receiver
- B User manual/warranty card
- 4. 1*AA battery (inside mouse)

System requirement

- 1. 1 x USB port 2. Windows* 7, Windows* 8, Windows* 10 or later,
- Android 3.2 and above: Mac OS 10.5 or later

Technical specifications

- 1. Connectivity: 2.4GHz wireless
- 2 Working distance: about 15m

- 2. working distance: about 15m 3. Number of buttons: 6 4. Button lifespan: 3 million clicks 5. Resolution: 800/1200/1600/2400/3200 DPI 6. Power supply: 1*AA Philips battery
- 7 Interface: USB wireless receiver
- 8. Product size: 117.2x74.8x39.3mm 9. Product weight: 97g ± 5g
- 10. Operating temperature range: 0 ° C to 40 ° C 11. Operating humidity range: 10% 85%.

Trouble shooting

- Make sure that the USB wireless receiver of the product is correctly plugged into the USB port of the computer.
 Make sure the computer meets the minimum system requirement.
- 3. If the distance between the product and the receiver exceeds an effective range, please reduce the distance for better performance.

If you can't solve the problem, please try to find the solution from Philips website or nearest retailer. Please do not disassemble the product by force.

- 1. Photoelectric technology can correctly detect the movement of mouse on most surfaces. Do not use the mouse on any reflective, transparent or uneven
- Please use dry and soft cloth to clean the product.
- 2. Nease use ut you and so trust in the teach the product.
 3. Do not disassemble the product by force.
 4. Do not direct the light from the bottom of the mouse to your eyes.
 5. Do not get in the rain or in the sun or fire.
 6. Do not flush directly with water.

Important safety and compliance information

of product and packing material Waste Electrical and Electronic Equipment-WEEE



Waste Extention and Exectionic Explorment-Wildle. May be a feed to the second of with your household waste instead, it is your responsibility to dispose of your waste equipment by making the product of the product of

CE Declaration of Conformity
This device consists with the requirements set out in the Council Directive on the Approximation of the Laws of the
Member States relating to Electromagnetic Compatibility Directive (2014/30/EU), RoHS directive (2011/65/EU) and
Radio Explainment Divertie (2014/32/EU) for Radio Explainment Divertie (2014/32/EU) for Radio Explainment Divertie (2014/32/EU) for Radio Explainment Divertie (2014/32/EU) point (2014/20/EU), RoHS directive (2014/32/EU), RoHS directive (2014/22/EU), RoHS directive (2014/22/EU), Ro

Federal Communications Commission (FCC) Notice
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15
of the FCC Ruse. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can adulate and forequency energy and, if not installation and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that letterence will not occur in a particular installation. He equipment does cause harmful interference to add or television recopritor, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Received no relocate the receiving arterina.
- Received no relocate the receiving arterina.
- Connect the designation between the equipment and receiver.
- Connect the designation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Connect the design or an experience drawful? Vectoricates for heigh.
- Changet to the design or experience and only Vectoricates for heigh.
- Changet or modifications not organally approved by the pasty responsible for compliance could void the user's subfrolly to people the the equipment.

THIS CLASS B DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE - CAUSING EQUIPMENT REGULATIONS.

FCC Compliance Statement
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Commission Federale de la Communication
Cet équipement a été testé et déclaré conforme auxilimites des appareils numériques de class B,aux termes de
l'article 15 Des règles de la FCC. Ces limites sont conques de façon à fourir une protection raisonnable contre les
interferences nuisibles dans le cadre d'une installation résidentielle.

CET appareil produit, utilise et peud émettre des hyperfréquences qui, si l'appareil n'est pas installé et utilisé selon les contigeres données, pouveir d'auers des inferferences nuisibles aux communications natific. Expendent, rien ne le les contigeres données peud l'expendent, peud d'interferences nuisibles pour la recipiton des signaux de radio ou le télévision, ce apput être décede n'ermant l'équipement, puis en le remettant en fonction. I'utilisatur pourrait essayer de corriger la situation en prenant les neues suivenirés au l'expendent peut de l'échaignement puis en le remettant en fonction. Tutilisatur pourrait essayer de corriger la situation en prenant les neues suivenirés de l'expendent peut de l'échaignement et le récepteur.

Augmenter la distance entre l'équipement et le récepteur.

- Demander l'aide du marchand ou d'un technicien chevronné en radio/ télévision

Toutes modifications n'ayant pas reçu l'approbation des services compétents en matière de conformité est susceptible d'interdire à l'utilisateur l'usage du present équipement.

CET APPAREIL NUMERIQUE DE LA CLASSE B RESPECTE TOUTES LES EXIGENCES DU REGLEMENT SUR LE



Thank you for purchasing a Philips IT accessory product. To ensure you a reliable after-sales service, please read the following instructions carefully. This product warranty period is valid for one year from the date of purchase (the date of receipt of the return receipt and the invoice date of the buyer).

Register your product and get support at www.philips.com/welcome

The following situations are not covered by after-sales service

- Unable to provide a valid warranty card and invoice (not including those that can prove the products is within the valid warranty period) or the alteration of the warranty without authorization.
- The product model and serial number on the warranty card are not in conformity with the physical product or without the distributor seal.

 3. The model number, serial number or production date code on the product has
- been altered, removed or made illegible.
- 4. The defect is the result of excessive use outside the intended purpose, e.g. non-stop use in a commercial environment.
- 5. Damage due to not used in accordance with product instructions.
- Damage caused by the use of pirated software or computer virus during use.
- 7. Damage caused by accident, damage, or repair from unauthorized service
- 8. Damage caused by force majeure
- 9. The product does not work properly due to missing connection caused by accident, signal interference or other influential factors during use.
- 10.For normal wear and tear defects, or by their nature consumable parts.

 11. The product does not function properly because it was not originally designed,
- manufactured or approved for use in the country where you use the product, which might occur when you imported the product.

If the functions of the product which you had purchased are defected or can not be used normally, please contact your local retailer or contact: Email: India.Callcentre@tpv-tech.com Hotline service: 1800 425 6396

Opening hours: 10 a.m. to 9 p.m. from Monday to Saturday & 10 a.m. to 6 p.m. on

The serial number of the product filled in the form must be consistent with the actual product. This certificate the primary instrument for the after-sales service, please safe keep it. If you need technical support, please show this warranty card, and we will provide quality and professional services.

Name	
Place of origin	
Model No.	
Serial No.	
Name	
Address	
Tel.	
Postcode	
Retailer	
Address	
Tel.	
Postcode	
Sale date	
Invoice No.	
Stamp & Signature	
	Place of origin Model No. Serial No. Name Address Tel. Postcode Retailer Address Tel. Postcode Sale date Invoice No.

Dear customer the above information is to be filled in by the seller Please cooperate with us. Thank you The following information shall be filled in by the maintenance agency and returned to the custor

Maintenance info.	Maintenance company name	
	Address	
	Tel.	
	Postcode	
	Document No.	
	Date	
	Signature	