





Specifications subject to change without notice.

© 2015 Speech Processing Solutions GmbH. All rights reserved. Philips and the Philips' shield emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V. All trademarks are the property of their respective owners.

Document version 1.0, 2015-01-01

VOICE TRACER

VTR8010



快速操作指南 Quick start guide


需要帮助？
Need help?

User manual
请查看包装盒中的使用手册
See the user manual stored on the recorder.
Online

请登录: www.philips.com/welcome.
Go to www.philips.com/welcome.




PHILIPS







1




2



3



4



2S

PHILIPS

REC018.mp3
00:00:00 01:18
00:03:12 00:03:12

OFF >> ON

Recording...
REC019.mp3
00:02:18 01:18
00:03:12 01:18

PLAY

Pause...
REC019.mp3
00:02:18 01:18
00:03:12 01:18

Saving...

Recording...
REC019.mp3
00:02:18 01:18
00:03:12 01:18

Saving... → Recording...
REC020.mp3
00:00:01 02:00
00:03:12 01:18

Goodbye

ON >> OFF

.mp3 → A B C D



2S

PHILIPS

REC001.mp3
00:00:00 01:18
00:03:12 00:03:12

OFF >> ON

REC001.mp3
00:02:18 01:18
00:03:12 01:18

REC002.mp3
00:02:45 01:18
00:03:12 00:03:12

..003..004..005..

REC001.mp3
00:02:18 01:18
00:03:12 01:18

REC001.mp3
00:02:18 01:18
00:03:12 01:18

2501

REC001.mp3
00:00:00 01:18
00:03:12 00:03:12

REC001.mp3
00:00:00 01:18
00:03:12 00:03:12

STOP

Play Mode
AB Repeat
Variable Spe...
Replay Times



Settings

儲存介質 Select Memory
文件夾選擇 Select Folder
錄音類型 Record type
數字降噪 Digital N.R
聲控 VA control
監听 Listen In

內置儲存器 Internal Memory
A文件夾 A Folder
PCM HPCM
禁用 禁用
Disable Disable
禁用 禁用
Disable Disable

卡存儲器 Card Memory
B文件夾 B Folder
C文件夾 C Folder
D文件夾 D Folder
SHQ HQ SP SLP
禁用 禁用
Enable Enable
禁用 禁用
Disable Disable

系統時間 System time
Time Mode
Current Time
Time Mode
Current Time
2012-01-01

定时录音 Record Timer
Record Time
Record Source
Record Length
Record Time
Record Source
Record Length
Record Time
Record Source
Record Length
30 Minutes
30 Minutes

分段录音 Auto Divide
背光時間 Backlight
語言 Language
关机设定 Auto off
格式化磁盘 Clear memory

不分段 30分钟 60分钟
OFF 30 MIN 60 MIN
Always on 15秒 30秒 45秒 60秒
S-Chinese 30S 3MIN 5MIN 10MIN
Always on 30S 3MIN 5MIN 10MIN

收音模式 Radio mode
Radio Mode
China
67.5