# Safety instructions

Register online at www.philips.com/welcome to ensure-

Product safety notification \*Additional benefits ceive notification - directly from the | that you'll receive all of the privilege


product recall or safety defect. special money-saving offers.

Know these **Safety** symbols



RISK OF FLECTRIC SHOCK DO NOT OPEN AUTION: TO REDUCE THE RISK OF FLECTRIC SHOCK, DO NOT REMOV

OVER (OR BACK). NO USER-SERVICEABLE PARTS ARE INSID REFER SERVICING TO QUALIFIED SERVICE PERSONNEL



The exclamation point within an equilateral triangle is intended to alert the user to the presence of importar operating and maintenance (servicing) instructions in he literature accompanying the apparatus

For fastest support visit us online for chat and self service

o reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

prevent electric shock, match wide blade of plug to wide slot, fully insert

# CHILD SAFETY:

PROPER TELEVISION PLACEMENT MATTERS

THE CONSLIMED ELECTRONICS INDUSTRY CARES

- Manufacturers, retailers and the rest of the consumer electronics industry are committed to making home entertainment safe and enjoyable As you enjoy your television please note that all televisions – new and old- must be supported on proper stands or installed according to the
- manufacturer's recommendations. Televisions that are inappropriately situated on dressers, bookcases, shelves, desks, speakers, chests, carts etc.. may fall over, resulting in injury.

# THINE IN TO SAFETY

- rniture on which the television is placed.
- ALWAYS install the television where it cannot be pushed, pulled over or

### WALL OR CEILING MOUNT YOUR TELEVISION


- v doubts about your ability to safely mount your television
- manufacturer and has a safety certification by an independent
- to walls and ceilings with steel studs or cinder block construction. If you

- secondary room after the purchase of a flat-panel television. Special
- AI WAYS place your older CRT television on furniture that is sturdy and
- ALWAYS make sure your older CRT television does not hang over the

# Important safety nstructions

- allow all instruction
- lean only with dry cloth
- Do not install near any heat sources such as radiators, heat registers, oves, or other apparatus (including amplifiers) that produce heat o not defeat the safety purpose of the polarized or grounding-ty
- nlug A polarized plug has two blades with one wider than the other nding type plug has two blades and a third grounding prong e wide blade or the third prope are provided for your safety. If the rided plug does not fit into your outlet, consult an electrician for enlacement of the obsolete outlet
- ct the power cord from being walked on or pinched particularly at plugs, convenience recentacles, and the point where they exit from
- Only use attachments / accessories specified by the manufacturer
- apparatus combination to avoid injury from tip-over nplug this apparatus during lightning storms or when
- supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

tle 820-40 of the NEC that provides guidelines for proper grounding nd in particular, specifies that the cable ground shall be connected the grounding system of the building, as close to the point of cable try as practical



- ALWAYS follow the manufacturer's recommendations for the safe **ALWAYS** read and follow all instructions for proper use of your television. NEVER allow children to climb on or play on the television or the
  - purposes other than those specified herein, confirmation of their validity and suitability must be obtained.
- ALWAYS route cords and cables connected to the television so that they United States patents. cannot be tripped over, pulled or grabbed. o further warranty is expressed or implied.

- **ALWAYS** use a mount that has been recommended by the television
- ALWAYS follow all instructions supplied by the television and mount
- ALWAYS make sure that the wall or ceiling where you are mounting the elevision is appropriate. Some mounts are not designed to be mounted

# Televisions can be heavy. A minimum of two people is required for a MOVING AN OLDER TELEVISION TO A NEW PLACE IN YOUR HOME

- Positioning the TV appropriate for its size and weight.

  NEVER place your older CRT television on a dresser where children may
  - arry and handle a large screen TV
- CTA.tech/safety Consumer Technology

- Read these instructions. Keep these instruction: Heed all warnings.
- o not use this apparatus near water
- not block any ventilation openings. Install in accordance with the

- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart,
- for long periods of time Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-

# Note to the CATV system installer:

# Example of antenna grounding as per NEC - National Electric Code

Trademarks are the property of Koninklijke Philips N.V. or their respective owners. Funai Corporation reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly. material in document is believed adequate for the intended use of **NEVER** place the television on furniture that can easily be used as steps. the system. If the product or its individual modules or procedures are

POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ART 250, PART H)

poration warrants that the material itself does not infringe any

# nai Corporation cannot be held responsible neither for any errors in the content of document nor for any problems as a result of the content in document. Errors reported to Funai Corporation will be adapted and published on the Funai Corporation support website as soon as possible.

# Pixel characteristics

ELECTRIC SERVICE EQUIDMENT

This LCD product has a high number of color pixels. Although it has effective pixels of 99.999 % or more, black dots or bright points of light (red, green or blue) may appear constantly on the screen. This is a structural property of the display (within common industry standards) and

### components are user serviceable. Do not open or remove covers to the inside of the product. Repairs may only be done by service centers and official repair shops. Failure to do so shall void any warranty, stated

# eration expressly prohibited in document, any adjustments of assembly procedures not recommended or authorized in document shall

Do not install the unit in direct sunlight or in a place subject to dust or

# Large screen TVs are heavy. 2 people are required to

- Make sure to hold the upper and bottom frames of the unit firmly as illustrated. nstall the unit in a horizontal and stable position.
- ni-mh Li-ion etc.) batteries

- Depending on the environment, the temperature of this unit may
- increase slightly. This is not a malfunction. When installing this unit in a temperate environment, avoid a place with rapid temperature changes
- Operating temperature: 41 °F (5 °C) to 104 °F (40 °C) This unit should not be used in a tropical environment as it has not been
- evaluated under such conditions.
   No objects should be placed directly on or under this unit, especially lighted candles or other flaming objects. Depending on your external devices, noise or disturbance of the picture and / or sound may be generated if the unit is placed too close to them
- In this case, please ensure enough space between the external devices Do not insert the AC power cord into the power socket outlet before all
- the connections are made.

  Ensure that you always have easy access to the AC power cord and outlet to disconnect the TV from the AC outlet.
- Before you move the TV, disconnect attached cables to prevent damage to connectors, especially the TV tuner. Be sure to unplug the AC power plug from the AC outlet before moving or carrying the unit
- When moving the TV and then setting it down, please be careful not to pinch the AC power cord under the unit Regulatory notices

WARNING: To prevent injury, this apparatus must be securely attached to

### the furniture / wall in accordance with the instructions. Tipping, shaking or rocking the unit may cause injury / death serious personal injury or death. Many injuries, particularly to

- children, can be avoided by taking simple precautions such as Using cabinets or stands recommended by the manufacturer Only using furniture that can safely support the TV.
- Ensuring the TV is not overhanging the edge of the Not placing the TV on tall furniture (for example, cupboards
- or bookcases) without anchoring both the furniture and the TV to a suitable support.

  Not placing the TV on cloth or other materials that may be located between the TV and supporting furniture.
  Educating the children about the dangers of climbing on

furniture to reach the TV or its controls. If your existing TV is being retained and relocated, the same

Do not place the unit on the furniture that is canable of being tilted by a child and an adult leaning, pulling, standing or climbing on it. A falling unit can cause serious injury or even death. In order to avoid interruption of ventilation, this unit should not be placed in built-in equipment such as a book cabinet rack etc. and the vents of this unit should not be covered ith anything such as a tablecloth, curtain, newspaper, etc. Make sure hat there is enough ventilation space (4" / 10 cm or more) around this

ress (b) to turn the unit on and go into standby mode. To completely rn off the unit, you must unplug the AC power plug from the AC power outlet. Disconnect the AC power plug to shut the unit off when trouble is found or not in use. The AC plug shall remain readily available.



Never use a gas duster on this TV. he gas trapped inside of this unit may cause ignition and explosion.



The packaging of this product is intended to be recycled. Contact your local authorities for information about how to recycle the For product recycling information, please visit - www.recycle.philips.com

### End of life directives

Philips pays a lot of attention to produce environmental-friendly products in green focal areas. Your new TV contains materials which can be cycled and reused. At the end of its life, specialized companies can dismantle the discarded TV to concentrate the reusable materials and to nize the amount of materials to be disposed of. Please ensure you dispose of your old TV according to local regulations.

# A Batteries usage

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

WARNING: Batteries (battery pack or battery installed) should not be exposed to excessive heat such as sunshine, fire or the like.

 Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad,

### Disposal of used batteries

cadmium however in certain localities, disposing batteries with household waste is not permitted. Please ensure you dispose of batteries according to local regulations.

Please pack the unit properly by following the diagram on the carton stand on the same side as the TV screen refer to

### Federal communications commission notice

equipment has been tested and found to comply with the limits for ass B digital device nursuant to part 15 of the ECC Rules ese limits are designed to provide reasonable protection against terference in a residential installation. This equipmen generates, uses and can radiate radio frequency energy and, if no istalled and used in accordance with the instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation reception, which can be determined by turning the equipment off and user is encouraged to try to correct the interference by one or more of the following measures:

- ncrease the separation between the equipment and the receiver
- sult the dealer or an experienced radio or television technician This device complies with part 15 of the FCC rules. Operation is subject

# including interference that may cause undesired operation.

nsible party: Funai Corporation, Inc. : 32PFL5505/F7 21061 S. Western Ave. Suite 210, Torrance, CA 90501,

modifications to this apparatus may cause harmful i Any modifications to the apparatus must be approved by Funa

# metallic RFI / EMI connector hoods to maintain compliance with FCC FCC statutory notice for wireless I AN adapter

ty responsible for compliance could void the user's authority to operate is transmitter must not be co-located or operated in conjunction with any

# ner antenna or transmitter

is equipment complies with FCC radiation exposure limits set forth for uncontrolled environment and meets the FCC radio frequency (RF) ure Guidelines. This equipment should be installed and operated ping the radiator at least 20 cm or more away from your body.

# pliance with FCC requirement 15.407(c)

ismission is always initiated by software, which is the passed dow ugh the MAC, through the digital and analog baseband, and finally to RF chip. Several special packets are initiated by the MAC. These are the ays the digital baseband portion will turn on the RF transmitter, which turns off at the end of the packet. Therefore, the transmitter will be nly while one of the aforementioned packets is being transmitted. In words, this device automatically discontinue transmission in case of er absence of information to transmit or operational failure.


### Downloading an electronic copy

- To obtain a more detailed electronic copy of document
- ose your country of location with language.
- ck the description or mode 5. Under product support, click "User manual".

he batteries supplied do not contain the heavy metals mercury and

# Preparing to move / ship the unit

To avoid damage to the screen, do not pack the



Funai Corporation Inc. does not warrant access to the portal or to any

of the services content software and advertising Funai Corporation

nc. may, in its sole discretion, add or remove access to any specific

Funai Corporation Inc. does not warrant Wireless Screencasting

compatibility with all source devices such as smartphones, tablet

laptops, etc. due to large variability in hardware, firmware, drivers,

any specific services, and content or software.

Wall mount

mount instruction book

Left and right side: 5.9 " (15 cm)

Wall mount bracket kit

services content software and advertising at any time. Although Funai

or software Funai Corporation Inc. does not warrant continued access to

oftware and implementation of wireless casting applications on these

compatibility and performance across a range of source devices. Funai

orporation Inc. does not warrant compatibility with specific source

Your product Brand Model # Screw dimension

32PFL5505/F7 SANUS AST16 M4 x 1.378 " (35 mm)

· Your TV meets the VESA standard for wall mounting. Consult with you

local dealer for a wall mount bracket which is compatible with your T

The recommended wall mount bracket kit (sold senarately) allows the

mounting of the TV on the wall.

For detailed information on installing the wall mount, refer to the wall

Funai Corporation is not responsible for any damage to the product

The wall mount bracket must be installed by experts

Install the wall mount bracket on a sturdy vertical wall

or injury to yourself or others if you elect to install the TV wall mount bracket or mount the TV onto the bracket on your own.

Funai Corporation is not liable for any accidents or injuries incurred while

If installed onto a ceiling or slanted wall the TV and wall mount bracket

may fall which could result in a severe injury.

Do not use screws that are longer or shorter than their specified length

damage inside the TV set. If screws too short are used this may cause

product or cause the product to fall, leading to an injury.
For safety reasons use 2 people to mount the TV onto a wall mounting

Do not mount the TV onto the wall mounting bracket while your TV is

plugged in or turned on. It may result in an electrical shock injury.

When installing the unit on the wall, allow this much space.

3.9 " (10 cm)

Do not fasten the screws by excessive force. This may damage the

installing this product, including but not limited to those noted below:

source devices. Although Funai Corporation Inc. will strive to enhance

rporation Inc. will strive to provide a good selection of services, conten

- ect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- to the following two conditions: (1) This device may not cause harmful rference, and (2)This device must accept interference received,

# Declaration of conformity

Telephone number:1833 978 3323 Modifications his apparatus may generate or use radio frequency energy. Changes o

# The user could lose the authority to operate this apparatus if an unauthorized change or modification is made.

FCC caution: Any changes or modifications not expressly approved by the

ctions to this device must be made with shielded cables with

FCC RF Exposure Compliance

- Point your browser to : www.nhilins.com/sunnort
- 3 Enter the product name or number in the search field. Alternatively

All other registered and unregistered trademarks are the property of their respective owners.



The terms HDMI and HDMI High-Definition Multimedia Interface and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



nufactured under license from Dolby Laboratorie olby, Dolby Audio, and the double-D symbol are trademarks of



Flectric Co. Ltd. is under license. Other trademarks and trade names.

Google, Google Play, Android, and related marks and logos are

including interference that may cause undesired operation

gistration and credit card information

nterference, and (2) this device must accept any interference received,

- are those of their respective owners
- trademarks of Google LLC.
  Use of this TV requires consent to Google Terms of Service and Privacy is device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful
- res and specifications are subject to change without notice. Portions of this software are copyright @ The FreeType Project (www Network services, content, and the operating systems and software of this Product may be subject to individual terms and conditions and changed, interrupted or discontinued at any time and may require fees,
- The American Academy of Pediatrics discourages television viewing for children younger than two years of age.

  Some features may require an always-on broadband internet connection, firmware update and/or a minimum bandwidth. Internet services vary by location.

# License

Funai Corporation, Inc. hereby offers to deliver, upon request, a copy of the complete corresponding source code for the copyrighted open source code packages, on an "AS IS" basis, used in this product for which such offer is requested by the respective licenses. This offer is valid up to three years after the product purchase to anyone in receipt of this information. To obtain source

code, please contact Funai Corporation, Inc. ou should write to Funai Service Corporation OSS Request, 2425 piegel Drive, Groveport, OH 43125, USA.

unai Corporation, Inc. disclaims any and all warranties and representations with respect to such software and related source code including quality reliability usability and accuracy and further disclaim all express implied statutory or otherwise including without limitation, any implied warranties of title, nonnfringement, merchantability, or fitness for a particular purpose. Funai Corporation, Inc. shall not be liable to make any corrections to the open source software or source code or to provide any support or assistance with respect to it. Funai Corporation, Inc. disclaims any and all liability arising out of or in connection with the use of this software and/or source code

# Limited warranty

is given your product becomes company property

price of the product

# Limited warranty one (1) year This warranty obligation is limited to the terms as set forth below.

Who is covered: This product warranty is issued to the original purchaser or the person receiving the product as a gift against defects in materials and

This warranty covers new products if a defect in material or workmanshi

occurs and a valid claim is received within the Warranty Period. At its option

company will either (1) repair the product at no charge, using new or

workmanship as based on the date of original purchase ("Warranty Period") from an Authorized Dealer. The original sales receipt showing the product name and the purchase date from an authorized retailer in considered such proof

### efurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new, or serviceable used parts and is at least functionally equivalent or most comparable to original product in current inventory, or (3) refund the original purchas

Replacement products or parts provided under this warranty are covered against defects in materials and workmanship from the date of the gainst defects in materials and working from the date of the eplacement or repair for ninety (90) days or for the remaining portion of ne original product's warranty, whichever provides longer coverage for you When a product or part is exchanged, any replacement item becomes you property and the replaced item becomes company property. When a refund

Note: Any product sold and identified as refurbished or renewed carries a ninety (90) day Limited warranty.

### met. Failure to follow all requirements can result in delay. What is not covered - Exclusions and limitations:

This Limited warranty applies only to new company manufactured products that can be identified by the trademark, trade name, or logo affixed to it. This Limited warranty does not apply to any hardware product or any software, even if packaged or sold with the product, as manufacturers, suppliers, or publishers may provide a separate warranty for their own products packaged with the bundled product.

Replacement product can only be sent if all warranty requirements are

The company is not liable for any damage to or loss of any programs

data or other information stored on any media contained within the product, or other additional product or part not covered by this warranty Recovery or reinstallation of programs, data or other information is no covered under this Limited warrant This warranty does not apply (a) to damage caused by accident, abuse misuse, neglect, misapplication, or non-supplied product, (b) to damage caused by service performed by anyone other than company approved Authorized Service Location (c) to a product or a part that has been

### sold "AS IS" without warranty of any kind by including refurbished product sold "AS IS" by some retailers

This Limited warranty does not cover: Shinning charges to return defective product

modified without written company permission, or (d) if any serial number

has been removed or defaced, or (e) product, accessories or consumable

- Labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna / signal source systems outside of the product Product repair and / or part replacement because of improper installation or maintenance connections to improper voltage supply power line surge
- appearance items due to normal wear and tear unauthorized repair or ther cause not within the control of the rner cause not witnin the control of the company. amage or claims for products not being available for use, or for lost

operate in any country other than the country for which it was designed

manufactured, approved and / or authorized, or repair of products

lightning damage retained images or screen markings resulting from

- data or lost software Damage from mishandled shipments or transit accidents when returning A product that requires modification or adaptation to enable it to
- damaged by these modifications. product used for commercial or institutional purposes (including but not limited to rental purposes)
- Product lost in shipment and no signature verification receipt can be ailure to operate per document.

### To obtain assistance. Contact the customer care center at: 1833 978 3323

Chat with us in English: https://tinyurl.com/v2e29xsq REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY FOR THE CONSUMER. WITH THE ISSUING COMPANY NOT LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIA DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OF PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS R A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN

Some states do not allow the exclusions or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights. You may have other rights which vary from state / province to state / province.

DURATION TO THE DURATION OF THIS WARRANTY.

Funai Service Corporation 2425 Spiegel Drive, Groveport, OH 43125, USA



Product design and user interface are for illustrative purposes only. Actual product and user interface may vary

# Quick start guide


Scan to call us:

Chat with us:



Scan to chat with u > Sunday











Hours of operation


> Monday - Saturday

- 9 AM to 9 PM EST
- 9 AM to 6 PM EST



**1** What's in the box

http://tinyurl.com/y2e29xsq





\*\*\*\*

# 2 Using the remote Controllable range for the remote Microphone 43 " or larger

# (I) (POWER)

Turns the TV on and off of standby.

# (TV GUIDE) Access to the Electronic Program Guide (EPG).

# The Google Assistant

Press the Assistant button on your remote to talk to your Google Assistant.

40° 40° 16′ (5 m)

# $\leftarrow$ (BACK)

Returns to the previous menu screen.

# **∃** (INPUT)

Change input source.

Select and change access to the attached devices such as Blu-ray player, gaming consoles, or cable box.

# (INFO)

1 ) ( 2 ) ( 3

7 (8 9

 $(\bullet)$ 

PHILIPS

Displays input and resolution information.

# 7 :≡ (OPTIONS)

Displays a list of menu options applicable to the active

# 8 • (CURSOR as **▲▼◄▶**) and **OK**

Moves to select an item and to determine on the various


# 9 (HOME)

Access to your apps, Live TV, input devices, settings, and the Google Play store.

# 10 PREV.CH

Direct access to the Live TV channels. Displays the last selected terminal or channel.

# 3 Installing the stands




Remove the tape on the bottom of the TV set and the plastic bag.

the screws, hold the stand to prevent it from falling.


Fasten the stand to the TV with Both stands should now be provided screws. While fastening securely fastened

• If you plan to wall mount your TV, refer to "Wall mount" on the reverse side of this guide for recommended wall mount bracket kit.

# 4 Connect the power and antenna, cable or satellite



# 5 Connection overview



# 6 Best experience

# Google account

Unleash your television's true potential. With a Google® account you can effortlessly expand your entertainment library via the Google Play store and Google Play app and also keep apps up-to-date.

While you can enjoy this Philips Android TV™ without a Google Account via the preinstalled selection of applications, we recommend a Google account to download additional apps from the Google Play Store or use the Google Assistant.

Simply login with your Google account.

It is recommended to create a new Google account specifically for your Android TV. A new account will prevent interference and syncing of your personal account. To create a new Google account, visit http://accounts.google.com/signup on your smartphone, tablet, or computer.

# Network router

The Philips 5000 series Android TV is equipped with wireless LAN 802.11ac for wireless streaming.

Wireless performance may be affected by various factors, including the distance between the TV and your Wi-Fi router. To improve wireless performance, we recommend placing your Wi-Fi router within 15 feet of your TV. The use of open or unencrypted Wi-Fi networks is not recommended, as these networks are not secured, and your data could be at risk.

If your Wi-Fi router was set up by your internet service provider (ISP), you may find a sticker on the bottom of your router indicating your Wi-Fi SSID and password.

# Set up Android TV with your Android smartphone or tablet

If you have an Android phone or tablet, you can quickly and easily set up your Android TV from your Android device. Pairing your Android device will allow you to wirelessly sync your Wi-Fi credentials. Google account, and Android TV compatible apps. During the initial setup, you will be prompted to set up your TV with your Android device, select **Yes**, and follow the on-screen instructions.

# Note:

Be sure to enable pairing mode on your Android device in the beginning.

# 7 The Google Assistant

# Activate the Google Assistant

To enjoy all of the benefits the Google Assistant can provide, an internet connection and a Google account are

Press your Assistant button on your remote to talk to the Google Assistant. To learn more about the Google Assistant visit https://assistant.google.com

# SafeSearch filter for Google search


SafeSearch can help you block inappropriate or explicit images from your Google search results. The SafeSearch filter helps block most adult content from your television. Parental supervision is strongly recommended.

- 1. On the Android TV home screen, select **Settings** in the upper right corner of the screen, and press **OK**.
- Select Device Preferences and press OK.
- Select the Google Assistant and press OK
- Select SafeSearch filter and press OK.

# 8 Explore your television

From the Android TV home screen, you can easily access movies. TV shows, music, apps, input devices.

To go back to the home screen at any time, press △ (HOME) on your remote.



With the Google Assistant, quickly access entertainment, control smart devices, get answers on screen, and more using your voice.

Toggle inputs between your favorite source devices.

### 3 Network condition

Display the network status and open network settings if selected.

# 4 Settings

Configure your television settings and connect to wireless devices.

# 5 Apps

You must sign in with a Google account to visit and download apps from the Google Play store.

# 6 How to rearrange channels

Within the row, you want to rearrange, press ◀ on your remote. To rearrange channels, select arrow  $(\blacktriangle/\blacktriangledown)$  icon, and press **OK**. Use  $\blacktriangle$   $\blacktriangledown$  to move up or down. Press **OK**.

To delete channels, select minus (-) icon, and press OK.

# 7 Install Additional Apps

Select the "+" and click on the Google Play Store to expand your entertainment library.

# 8 How to move or delete applications

Select the application and long press **OK** on your remote.

To move, select **Move** in the list, and press **OK**. Use **◄** ► to move left or right. Press **OK**. To delete, select **Remove from favorites** in the list, and press **OK**.

# 9 Live TV/Antenna


The Live TV channels feature on Android TV loads television shows, sports, news, and more from your participating TV apps or Antenna / OTA TV tuner so you can watch them all in one place.

To select channels, use **CH + / -** on your remote. For installation of TV channels using a set-top box, go to " 4 Connect the power and antenna, cable or satellite."

# Add channels

To add for the first time or additional channels, please follow the steps below:

1. On the Home menu, go to the Apps row and select How to...



- 2. Select Live TV to open channel installation page. Once open, select Setup and press OK.
- 3. Select your signal type **Antenna / Cable** to start the channel installation.



# Channel List

Press **OK** while viewing Live TV to open channel list. Based on the type of channels installed, select with the yellow color key Broadcast (conventional TV channels) or Network (internet TV channels).

### Program guide

To view the latest TV program schedule, press **Œ (TV GUIDE)** on your remote.

Live TV feature is only compatible with antenna and select cable broadcasting. To access your cable box or other source inputs, you must press (INPUT) on your remote.

For further assistance, call the customer support service in your country. - To obtain assistance, contact Philips customer care center;

In the U.S.A., Canada, Puerto Rico, or the U.S. Virgin Islands 1833 978 3323 Enter below the model and serial numbers located on the left side and the rear of the TV cabinet.

For complete instructions, please visit www.philips.com/support to download the full version of the online user manual.

This product has been manufactured by and is sold under the responsibility of Funai Corporation, Inc., and Funai Corporation, Inc. is the warrantor in relation to this product.

The Philips trademark and the Philips shield emblem are registered trademarks of Koninklijke Philips N.V. used under license.

