




- 1 使用Line-out 线将SPEECHMIKE与电脑相连，再将USB线如电脑相连，连接USB后设备可作为鼠标来使用。



- 2 打开PC端语音转文本软件



Specifications subject to change without notice.

Trade marks are the property of Royal Philips or their respective owners.

© 2015 Speech Processing Solutions GmbH. All rights reserved. Philips and the Philips' shield emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V. All trademarks are the property of their respective owners.

Document version 1.0, 2015-01-01

PHILIPS

VoiceTracer

多功能语音麦克风

VTR5160

快速操作指南 Quick start guide



User manual

请查看包装盒中的使用手册

See the user manual stored on the recorder.


Online

请登录 : www.philips.com/welcome.


Go to www.philips.com/welcome.



VTR5160



×2




软件盘
CD





唱歌模式



短按K1按键即可进入唱歌模式，在此唱歌模式下打开接入line-out线，打开手机的唱歌平台如（唱吧、全民K歌等平台）即可进入唱歌模式。可以通过调节混响、高低音、声音大小来调节音效达到一个最佳的唱歌模式。



录音模式

1



长按“录音”键进入录音

长按“录音”键进入录音，K1, K2的LED灯会一起亮，开始录音时K1, K2的LED灯会交替闪烁，同时“呼吸灯”为红色常亮状态。

2



短按“录音”键保存并退出录音

短按“录音”键保存并退出录音，K1, K2的LED指示灯不再交替闪烁，并返回K歌模式。




PC端软件



登录界面

输入正确的产品序列号以及登录密码，点击登录即可使用此软件。



录音界面

开始录音、暂停录音、保存录音。



实时听写

选择实时听写菜单，进去后，可以对边说边翻译，在此界面也可以对翻译后的文本编辑、保存。



主界面

录音、语音转文本、实时听写、文件目录、语言设置、浏览窗口。



语音转文本

语音转文本界面可以保存文本，编辑文本。


文件名	创建日期	大小
RECO01.txt	2018/12/28 08:32:15	19Kb
RECO02.txt	2018/12/28 08:32:15	19Kb
RECO03.txt	2018/12/28 08:32:15	19Kb
RECO04.txt	2018/12/28 08:32:15	19Kb
RECO05.txt	2018/12/28 08:32:15	19Kb
RECO06.txt	2018/12/28 08:32:15	19Kb
RECO07.txt	2018/12/28 08:32:15	19Kb
RECO08.txt	2018/12/28 08:32:15	19Kb

文件目录

选择文件目录菜单，进去后，可以浏览录音文件和文本文件列表。可点击打开文本文件的内容。




1



开

长按开关机键2到3秒钟

2



关

长按开关机键2到3秒钟