

背面

正面

**PHILIPS**  
VoiceTracer  
智能录音笔  
VTR5103

**快速操作指南**  
Quick start guide

**VTR5103**

Specifications subject to change without notice.  
Trade marks are the property of Royal Philips or their respective owners.  
© 2020 Speech Processing Solutions GmbH. All rights reserved. Philips and the Philips' shield emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V. All trademarks are the property of their respective owners.  
Document version 1.0, 2020-07-29

**User manual**  
请查看包装盒中的使用手册  
See the user manual in the gift box.  
**Online**  
请登录: [www.philips.com/welcome](http://www.philips.com/welcome)  
Go to [www.philips.com/welcome](http://www.philips.com/welcome).

**PHILIPS**

**START** **STOP**

录音键  
关机/电源键  
停止/返回键  
上一曲/音量-  
确定/播放键  
菜单键  
下一曲/音量+  
音量键

开机: 拨动“”键 2~3秒机器开机, 并停在语音停止界面。  
录音: 在开机待机界面, 往上推“”键进去录音, 录音时红色指示灯亮, 往下推“”键保存录音。  
播放: 触摸“”播放当前录音文件。  
调节音量: 在音量状态下可调节音量。  
+ / : 下一曲/音量+, 在播放模式下为下一曲; 在调节音量设置状态下为增加音量。  
- / : 上一曲/音量-, 在播放模式下为上一曲; 在调节音量设置状态下为减小音量。

物料名:	VTR5103 快速指南	设计者、日期:	2020.8.21	公差: <input type="checkbox"/> 1. 说明书、保修卡、快速指引尺寸公差: ±1mm <input type="checkbox"/> 2. 贴纸类尺寸公差: ±0.3mm <input type="checkbox"/> 3. 机身贴纸类(包括贴于凹槽内)尺寸公差: ±0.3mm <input checked="" type="checkbox"/> 4. 彩盒尺寸公差: ±0.3mm <input type="checkbox"/> 5. 彩卡(纸内衬)尺寸公差: ±0.3mm <input type="checkbox"/> 6. 吸塑类外径尺寸公差: ±0.5mm <input type="checkbox"/> 7. 珍珠棉内衬: ±2mm <input type="checkbox"/> 8. 袋类(PE袋、珍珠棉袋、便携/绒布袋)尺寸公差: ±0.5mm <input type="checkbox"/> 9. 纸品类(外箱、内箱)尺寸公差: ±0.5mm <input type="checkbox"/> 10. 平卡、刀卡、PDQ尺寸公差: ±1mm <input type="checkbox"/> 11. 吊绳类尺寸公差: ±1mm
规格描述:	尺寸: 320X140mm(4折页正反面) 材质: 128g铜版纸	印刷颜色:	CMYK	
品质要求:	<input type="checkbox"/> 公司标准 <input checked="" type="checkbox"/> PHILIPS标准 <input type="checkbox"/> Best Buy标准 <input type="checkbox"/> 其它标准	签样要求:	<input type="checkbox"/> 无需签样 <input checked="" type="checkbox"/> 需签样	