

Specifications subject to change without notice.

Trade marks are the property of Royal Philips or their respective owners.

© 2015 Speech Processing Solutions GmbH. All rights reserved. Philips and the Philips' shield emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V. All trademarks are the property of their respective owners.

Document version 1.0, 2019-01-01

PHILIPS

VoiceTracer

数码录音笔

VTR7800

快速操作指南 Quick start guide



User manual

请查看包装盒中的使用手册

See the user manual in the gift box.


Online

请登录: www.philips.com/welcome.

Go to www.philips.com/welcome.




VTR7800






1



2



OFF >> ON

2S

PHILIPS
REC0056 MP3
00:00:00

A B
D C

正在保存

PHILIPS

ON >> OFF

.mp3 → A B C D



OFF >> ON

2S

PHILIPS
REC0056 MP3
00:00:00

A B
D C

..003..004..005..

正在播放

PHILIPS

ON >> OFF

+

-

STOP



Settings

Recording quality
录音品质
Recording scene
录音场景
Voice activation
声控
Auto divide
自动切分

Date/times
日期/时间

Auto off
自动关闭

Formatting Device
格式化设备
Recording light
录音指示灯
Device sounds
设备声音
Memory select
内存选择
Information
信息
Reset default
恢复出厂设置

PCM 24 bit/96 KHz
PCM 16 bit/48 KHz
PCM 16 bit/32 KHz
MP3 192 Kbps
MP3 128 Kbps
Standard
Interview mode
Conference mode
Classroom
Long distance
日记模式
采访模式
会议模式
教学模式
远距离模式
Disable
Enable
启用
禁用
Off 30 min
60 min
关 30分钟
60分钟

Yes
是
On
开
On
开
Internal
内置
Memory info
磁盘信息
Reset default
是
Yes

No
否
Off
关
Off
关
Micro-SD
Micro-SD
Firmware ver
固件版本
No
否
No