



>75% recycled paper
>75% papier recyclé

© 2018 Koninklijke Philips N.V.
All rights reserved
3000.033.5052.4 (05/02/2019)



1



2



English

Important safety information

Only use this product for its intended purpose. Read this information carefully before you use the product and its accessories, and save it for future reference. Misuse can lead to hazards or serious injuries. Accessories supplied may vary for different products.

Warning

- Keep the appliance and the supply unit dry (Fig. 1).
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Only use the appliance to remove hair from or trim areas below the neck (except the inner labia).
- Only use original Philips accessories or consumables. Only use detachable supply unit HQ8505.
- Do not use a damaged appliance. Replace damaged parts with new Philips parts.
- Do not modify the supply unit.
- Do not use the supply unit in or near wall sockets that contain an electric air freshener to prevent irreparable damage to the supply unit.
- Use and store the product at a temperature between 5 °C and 35 °C.
- Because of hygiene, only one person should use the appliance.
- Do not use the appliance on irritated or damaged skin, varicose veins, spots or moles (with hairs). Consult a doctor first if you have diabetes mellitus, haemophilia, reduced immune response or immunodeficiency.
- When you first start using the appliance, some skin irritation or redness is normal. When your skin gets used to the appliance, skin irritation decreases.
- To prevent damage or injury, keep the operating appliance away from scalp hair, eyebrows, eyelashes, clothes etc.
- Do not exfoliate immediately after epilation, as this may intensify possible skin irritation caused by epilation.
- Do not use bath or shower oils when epilating, as this may cause serious skin irritation.
- Never use compressed air, scouring pads, abrasive cleaning agents or aggressive liquids to clean the appliance.
- Make sure you push the small plug completely into the socket of the appliance. Once you have plugged it in fully, you hear a click.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Epilation tips

- Move the appliance against the direction of hair growth, with the on/off slide pointing in the direction in which you move the appliance.
- Place the appliance on the skin at an angle of 90°.
- Your skin must be clean, entirely dry and free from grease. Do not use any deodorant, makeup or cream before epilating.
- The optimum hair length for comfortable epilation is 3-4 mm. If hairs are longer, trim them before epilating.

Replacement

Shaving head (if supplied): Replace the cutting unit of the shaving head every two years or sooner if you use it more than twice a week. Always replace the cutting unit with one of the original type.

Support

For all product support such as frequently asked questions, please visit www.philips.com/support.

Recycling

- This symbol means that electrical products shall not be disposed of with normal household waste (Fig. 2).
- Follow your country's rules for the separate collection of electrical products.

Türkçe


Önemli güvenlik bilgileri

Bu ürünü sadece kullanım amacına göre kullanın. Ürünü ve aksesuarlarını kullanmadan önce bu bilgileri dikkatlice okuyun ve gelecekte başvurmak üzere saklayın. Yanlış kullanım, tehlikelere veya ciddi yaralanmalara yol açabilir. Cihazla birlikte verilen aksesuarlar ürünlere göre farklılık gösterebilir.

Uyarı

- Cihazı ve besleme ünitesi kuru (Şek. 1) halde tutmaya özen gösterin.
- Bu cihazın 8 yaşın üzerindeki çocuklar ve fiziksel, motor ya da zihinsel becerileri gelişmemiş veya bilgisi ve tecrübesi olmayan kişiler tarafından kullanımı sadece bu kişilerin nezaretinden sorumlu kişilerin bulunması veya cihazın güvenli kullanım talimatlarının bu kişilere sağlanması ve olası tehlikelerin anlatılması durumunda mümkündür. Çocuklar cihazla oynamamalıdır. Temizlik ve kullanıcı bakımı gözetim olmadan çocuklar tarafından yapılmamalıdır.
- Cihazı sadece boynun altında kalan bölgelerdeki (vajinal iç dudak hariç) tüyleri almak veya kısaltmak için kullanın.
- Yalnızca Philips tarafından üretilmiş aksesuar ve sarf malzemeleri kullanın. Yalnızca çıkarılabilir besleme ünitesi HQ8505 kullanın.
- Hasar görmüş cihazları kullanmayın. Hasar görmüş parçaları yeni Philips parçalarla değiştirin.
- Besleme ünitesinde değişiklik yapmayın.

- Besleme ünitesini, üniteyi telafisi mümkün olmayan hasarlardan korumak için elektrikli oda spreyi içeren duvar soketlerinde ya da bunların yakınında kullanmayın.
- Ürünü 5 °C ila 35 °C arası sıcaklıklarda kullanın ve saklayın.
- Hijyen nedeniyle cihazı sadece bir kişi kullanmalıdır.
- Cihazı tahriş olmuş veya hasar görmüş ciltlerde, varisli damar veya leke ve benli ciltlerde (üzerinde kıl olan) kullanmayın. Diyabet (şeker hastalığı), hemofili, düşük bağışıklık yanıtı veya bağışıklık yetersizliği gibi hastalıklarınız varsa önce bir doktora danışın.
- Cihazı ilk kez kullanmaya başladığınızda ciltte bir miktar tahriş veya kızarıklık oluşması normaldir. Cildiniz cihaza alışıkça cilt tahrişi zamanla azalacaktır.
- Hasara veya yaralanmaya yol açmamak için çalışır durumdaki cihazı saç, kaş, kirpik, kıyafet ve benzerinden uzak tutun.
- Epilasyonun neden olabileceği cilt tahrişini artırılabileceğinden epilasyondan hemen sonra peeling uygulamayın.
- Epilasyon yaparken, ciddi cilt tahrişlerine neden olabileceği için banyo ve duş yağları kullanmayın.
- Cihazı temizlemek için kesinlikle basınçlı hava, ovalama bezleri, aşındırıcı temizlik ürünleri ya da zarar verici sıvılar kullanmayın.
- Küçük fişi cihazın soketine tamamen bastırdığınızdan emin olun. Fişi tamamen taktıktan sonra bir klik sesi duyarsınız.



Elektromanyetik alanlar (EMF)

Bu Philips cihaz, elektromanyetik alanlara maruz kalmaya ilişkin geçerli tüm standartlara ve düzenlemelere uygundur.

Epilasyon ipuçları

- Cihazı, açma/kapama sürgüsü hareket ettirdiğiniz yöne bakacak şekilde, tüylerin çıkış yönünün tersine hareket ettirin.
- Cihazı cildinize 90° açı yapacak şekilde yerleştirin.
- Cildinizin temiz, tamamen kuru ve yağsız olması gerekir. Epilasyondan önce herhangi bir deodorant kullanmayın, makyaj malzemesi veya krem sürmeyin.
- Konforlu bir epilasyon için ideal tüy uzunluğu 3-4 mm'dir. Tüyler daha uzunsa epilasyondan önce kısaltın.

Değişim

Tıraş başlığı (varsa): Ürünü haftada iki kereden daha fazla kullanırsanız tıraş başlığının kesme ünitesini iki yılda bir veya daha sık değiştirin. Kesme ünitesini her zaman orijinal bir kesme ünitesiyle değiştirin.

Destek

Sık sorulan sorular gibi ürünle ilgili tüm destek konuları için lütfen www.philips.com/support adresini ziyaret edin.

Geri dönüşüm

- Bu simge, elektrikli ürünlerin normal ev atıklarıyla birlikte atılmaması gerektiğini belirtir (Şek. 2).
- Elektrikli ürünlerin ayrı olarak toplanmasına ilişkin ülkenizde yürürlükte olan yönetmeliklere uyun.

