

始终如一地为您提供帮助

在以下网站上注册产品并获得支持

www.philips.com/welcome








SPA5210
SPA5210B



用户手册

PHILIPS



注

- 安装笔记本 SoundBar 之前，请确保电脑上的 **Windows** 设备管理器中已列出有效的 USB 控制器。
- 使用之前，请确保笔记本 SoundBar 安装正确。
- 切勿在笔记本 SoundBar 播放声音时拔出 USB 连接器。



本产品采用可回收利用的高性能材料和组件制造而成。请熟悉当地专门为电子和电器产品，包括那些标有叉线有轮垃圾箱符号的产品所制订的分门别类的收集机制。请遵守当地规定，不要将旧产品丢弃到普通生活垃圾中。

系统要求：






个人电脑	MAC
Windows® 98SE、 Windows® ME、 Windows® 2000、 Windows® XP 或 Windows® Vista™	Mac OS9/OS® X 或 更高版本
经认证的 USB 控制器	内置 USB 连接

安装：

- 1 滑下固定夹（图 1）。
- 2 将笔记本 SoundBar 夹在笔记本屏幕的顶部，轻轻地拧紧背面的螺钉（图 1）。
- 3 将 USB 接口插入笔记本的 USB 端口（图 2）。
- 4 打开多媒体应用程序软件，然后调节音量（图 3）。
- 5 使用 SoundBar 之后，退出多媒体应用程序软件。
- 6 从笔记本上拔下 USB 电缆，轻轻松开螺钉从屏幕的顶部取下 SoundBar。
- 7 将 USB 电缆和插头缠绕在 SoundBar 上的线槽中，然后将笔记本 SoundBar 放入软袋中（图 4 & 5）。

如果电脑无法检测到笔记本 SoundBar，请执行以下步骤：

在个人电脑上	在 Mac 上
1. 单击控制面板。 2. 双击声音和音频设备图标。 3. 在声音和音频设备属性中，选择音频选项卡。 4. 在声音播放中，选择 Philips SPA5210 。	1. 单击 System Preferences （系统首选项）。 2. 单击声音图标。 3. 打开 Output （输出）并选择 Philips SPA5210 。 4. 通过多媒体软件播放音乐。





Specifications are subject to change without notice

2014 © WOOX Innovations Limited. All rights reserved.

This product was brought to the market by WOOX Innovations Limited or one of its affiliates, further referred to in this document as WOOX Innovations, and is the manufacturer of the product. WOOX Innovations is the warrantor in relation to the product with which this booklet was packaged. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V.