
Register your product and get support at www.philips.com/welcome




PHILIPS


Æ

EN Installation Guide









PHILIPS

Overview of parts 1

These are the supplied parts needed to connect and install this unit. 1 In-car audio system 2 Sleeve

3 Front panel 4 Trim plate 5 Rubber cushion 6 Disassembly tools 7 Screws 4 pieces

Connect wires

Caution

· Ensure that all loose leads are insulated with electrical tape.

For cars with ISO connectors 2 3

- 1 Pull out the ISO connectors from car dashboard and connect them to the bigger end of the supplied standard
- 2 Connect the other end of the standard connector to the u
- 3 Connect the antenna and an illustrated, if applicable.

	Connector	Connect to
1	REAR LINE OUT R	Rear right
		speaker
2	REAR LINE OUT L	Rear left speaker
3	SUB OUT	Subwoofer
4	ANTENNA	Antenna

e RED

f BLUE

g BLACK Ground h Orange/ Illumination switch

5

-12V car battery

Ignition key +12V DC

Motor/electric antenna

Amplifier relay control

when ON/ACC

relay control lead/

lead

1 Press (1) to turn on the unit. • To turn off the unit, press (1) for 3 energized at all seconds.

1 Press MENU/DISP for 3 seconds.

5 Turn (1) anti-clockwise to set minute.

3 Turn ① clockwise to set hour.

4 Press () to confirm.

6 Press ① to confirm.

Press ▲ or ▼ repeatedly to until the cur-rently time is displayed.

5 Install the sleeve into the dashboard and

6 Place the rubber cushion over the end of

7 Slide the unit into the dashboard until you

8 Reconnect the negative terminal of the car

the bolt.

battery.

Turn on

Set clock

hear a click sound.

bend the tabs outward to fix the sleeve.

- Insert the right side of the panel in the
- 2 Press the left side of the panel and point
- 4 Attach the trim plate.

- If the car does not have an on-board drive or navigation computer; disconnect the negative terminal of the car battery. If you disconnect the car battery in a car that has an on-board drive or navigation
- computer, the computer may lose its memory. If the car battery is not disconnected, to avoid short-circuit, ensure that bare
- wires do not touch each other 2 Remove the two screws on the top of the
- unit
- supplied disassembly tools.
- 4 Ensure that car dashboard opening is within these measurements:

Play audio files

- 2 Insert a CD with the printed side facing up.
- 3 Close the panel.
- 4 Press ▶II , to start play. To pause CD play, press ▶II . • To resume CD play, press ▶II again.

Insert the USB device

- 1 Open the cover marked $rac{1}{2}$ on the front
- 2 Insert the USB device into the USB socket. → ToThe unit starts playing from the USB device automatically.

© 2008 Koninklijke Philips Elect nics N.V. All rights reserved.

A 100% recycled paper

For cars with ISO connectors 3 4

Caution

Be sure to connect the black ground (earth) lead first.

- Connect the antenna and amplifier as illustrated, if applicable.
- 2 Cut off the bigger end of the supplied stan-dard connector.
- 3 Check the car's wiring carefully and connect them to the supplied standard connector. 4 Connect the supplied standard connector to the unit.
- Green/black Left speaker 1 (Rear) strip
 - White/black Left speaker strip (Front)
 - 3 Gray/black Right speaker (Front) othin ht speaker
 - ear)


	suip		(110
rd connector:	4	Purple/black	Right
the supplied unit.		strip	(Rea
umplifier as			

- 11	Orange/	illuminau
	white	
i	YELLOW	To the +
		which is e









3 Release the panel to engage the left side.

Mount in the dashboard 5

- Press MENU/DISP repeatedly until the clock is displayed.
- Listen to radio

View clock

- 1 Press SOURCE repeatedly to select Tuner:
- 2 Press or to select band: [FM1], [FM2], [FM3], [AM1], or [AM2].
- 3 Press ₩ or ₩ to tune to a radio station
- manually.
 To search for a radio station automatically, press SEARCH.
- 3 Remove the mounting sleeve with the