


www.philips.com/welcome




EN Quick Start Guide











Overview of parts 1

These are the supplied parts needed to connect and install this unit.

- 1 In-car audio system
- 2 Sleeve
- 3 Front panel
- 4 Standard connector
- 5 Trim plate (2 pieces)
- 6 Rubber cushion
- 7 Disassembly tools
- 8 Screws 4 pieces

Connect wires



Caution

Ensure that all loose leads are insulated with electrical tape.

For cars with ISO connectors 2 3

- Pull out the ISO connectors from car dashboard and connect them to the bigger end of the supplied standard connector.
- 2 Connect the other end of the supplied standard connector to the unit.
- Connect the antenna and amplifier as illustrated, if applicable.

	Connector	Connect to	
1	MIC	Microphone	
2	REAR LINE	Rear right	
	OUT R	speaker	
3	REAR LINE	Rear left speaker	
	OUT L		
4	SUB OUT	Subwoofer	
5	ANTENNA	Antenna	

For cars with ISO connectors 3 4



- Be sure to connect the black ground (earth) lead first
- Connect the antenna and amplifier as illustrated, if applicable.
- Cut off the bigger end of the supplied standard connector.
- Check the car's wiring carefully and connect them to the supplied standard connector.
- Connect the supplied standard connector to the unit.

1	Green strip	/black	Left speaker (Rear)
2	White strip	/black	Left speaker (Front)
3	Gray/b strip	olack	Right speaker (Front)
4	Purple strip	e/black	Right speaker (Rear)
е	RED	Ignition key +12V DC when ON/ACC	
f	BLUE	relay co	electric antenna ntrol lead/ er relay control
g	BLACK	Ground	
	Orange/ white	Illumination switch	
i	YELLOW		-12V car battery energized at all

times



- · Check wire connection before you mount the unit into a car.
- If preset radio stations are lost when the ignition key is turned **OFF** and then back **ON**, reconnect the red leads crosswise to the yellow ones.

Mount in the dashboard 5

- If the car does not have an on-board drive or navigation computer, disconnect the negative terminal of the car battery.
 - If you disconnect the car battery in a car that has an on-board drive or navigation computer, the computer may lose its
 - If the car battery is not disconnected, to avoid short-circuit, ensure that bare wires do not touch each other.
- Remove the two screws on the top of the
- Remove the mounting sleeve with the supplied disassembly tools.
- Install the sleeve into the dashboard and bend the tabs outward to fix the sleeve.
- Place the rubber cushion over the end of the holt
- Slide the unit into the dashboard until you hear a click sound
- Reconnect the negative terminal of the car battery.

Attach the front panel 5

- Attach the trim plate.
- Insert the right side of the panel in the chassis until it is correctly engaged.
- Press the left side of the panel and point the left hole at the left pillar.
- Release the panel to engage the left side.

Turn on

- Press ① to turn on the unit.
 - To turn off the unit, press ① for 3 seconds.

Set clock

- Press **MENU/DISP** for 3 seconds.
- Press \blacktriangle or \blacktriangledown repeatedly to until the currently time is displayed.
- Turn ① clockwise to set hour.
- Press (1) to confirm
- Turn ① anti-clockwise to set minute.
- Press (1) to confirm

View clock

Press MENU/DISP repeatedly until the clock is displayed.

Listen to radio

- Press **SOURCE** repeatedly to select Tuner.
- Press or to select band: [FM1], [FM2], [FM3], [AM1], or [AM2].
- Press o r ▶ to tune to a radio station manually,
 - To search for a radio station automatically, press **SEARCH** for 3 seconds.

Pairing bluetooth devices

You can pair your bluetooth device with the unit as follows:

- Turn on bluetooth function on the device
- Setup bluetooth fuction on your device.
- Select "CEM250" in the pairing list.
- Enter default password "0000".
 - "[CONNECT]" is displayed on the panel if pairing succeeds.
- Press and hold **SOURCE** to disconnect Bluetooth connection.



• ou can hold **SOURCE** again to reconnect last used Bluetooth device.

Make a call

- 1 Press SOURCE repeatedly to select BT MUSIC.
- 2 Press $\boldsymbol{\epsilon}$.
- Press ▲ or ▼ to select from the following list:
- **DIAL NUM**: dial number directly
- **DIALLED**: dialed number
- MISSED: missed call
- RECEIVED: received call
- ME PBK: Phone directory
- SIM PBK: SIM directory
- 4 Press O to confirm the selection.

To dial a number directly, select **DIAL NUM**.

- 1 Press 0-9 to enter phone number.
 - Press ◄•/▶ to change a number.
 - Press to reset entered numbers.
- 2 Press \boldsymbol{c} to dial.

To use a number in call log or directory, select the option other than **DIAL NUM**.

- 1 Turn \circ to select a number from call log or directory.
- 2 Press c to dial.

Terminate call

1) Press \frown to terminate call.



CLASS 1 LASER PRODUCT

