





Register your product and get support at
www.philips.com/welcome

HTS5120



Quick Start


PHILIPS




AC Adapter




Power Cord




SCART Adapter



Component





Composite



HDMI




FM Antenna







1




①




②
















9



10




2





3

DISC




FM












MP3



USB









www.philips.com/support



Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2010 © Koninklijke Philips Electronics N.V. All rights reserved.
sgythy_1003/12_v2

