

Philips
CD Soundmachine

CD ripping

AZ1845



Great portable sound

The Philips CD soundmachine will free your favorite digital tunes from your portable music player and let you enjoy them all in powerful sound - anytime, anywhere. It also features one-touch MP3 digital recording - no PC required.

Easy to use

- CD ripping for one-touch MP3 digital recording
- MP3 Link for portable music playback
- Stereo headphone socket

Multisource music enjoyment

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- FM/MW tuner for radio enjoyment

Powerful sound you can hear and feel

- Bass Reflex Speakers for a deep, powerful sound
- Dynamic Bass Boost for deep and dramatic sound
- 10.2 cm (4") full range speakers for powerful sound
- 2x1W RMS total output power

PHILIPS

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program

Connectivity

- USB: USB host
- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Tuner/Reception/Transmission

- Antenna: FM antenna
- Tuner bands: FM, MW

Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2
- Loudspeaker enhancement: bass reflex speaker system
- Speaker grille finishing: metal

Convenience

- Display Digits: 3
- Loader type: top
- Display type: LCD display

Accessories

- Cables/Connection: *Flat pin adaptor, 3.5 mm stereo line in cable, power cord
- User Manual: B-Portuguese, Spanish
- Warranty: Warranty Certificate

Dimensions

- Gross weight: 3.8 kg
- Packaging width: 457 mm
- Packaging height: 283 mm
- Packaging depth: 210 mm
- Weight: 2.8 kg
- Main unit depth: 240 mm
- Main unit height: 168 mm
- Main unit width: 420 mm

Power

- Battery type: D size (LR20)
- Battery voltage: 1.5 V
- Power supply: 110 - 127V and 220 - 240V AC voltage selectable
- Number of batteries: 6

Audio recording

- Recording media: USB device
- USB recording modes: instant record, programmed tracks, single disc, single track
- USB recording sources: CD

Highlights

CD ripping

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch operation and no computer needed.

Bass Reflex Speakers

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

USB Direct

With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2014-02-05

Version: 4.0.7

12 NC: 8670 000 40377
EAN: 87 12581 42883 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel
because this may damage your hearing.