



在以下网站上注册产品并获得支持 www.philips.com/support

请在使用本产品之前阅读并理解所有说明。因未遵守说明而 造成的损坏不在保修范围内。

帮助和支持

有关广泛的在线支持,请访问 www.philips.com/support

- 下载用户手册和快速入门指南 • 观看视频教程(仅限于选定的型号)
- 查找常见问题 (FAQ) 的答案 • 通过电子邮件向我们发送问题

• 与支持代表聊天。 请按照网站上的说明选择您的语言,然后输入您的产品

或者, 您可以联系所在国家/地区的客户服务。联系之前, 请记下产品的型号和序列号。您可在产品的背面或底部找到 此信息。

安全

小心触电或发生火灾!

源插座断开连接。

• 在建立或更改任何连接之前,请确保所有设备均已与电

- 切勿让本产品及附件与雨或水接触。切勿将液体容器 (如花瓶)置于产品旁边。如果有液体溅到本产品表面 或内部,请立即断开其电源。请与客户服务联系,对产 品进行检查后再使用。
- 切勿将本产品和附件放置在靠近明火或其它热源的地 方,包括阳光直射处。
- 切勿将物体插入本产品的通风槽或其它开口。 • 将电源插头或设备耦合器用作断电设备时,该断电设备
- 应可以随时使用。 • 不可将电池(电池组或安装的电池)置于高温环境,如阳光
- 直射处、明火或类似环境。 • 在雷电天气之前,应断开本产品的电源。
- 断开电源线时,应始终握住插头,而不能拉电缆。 小心短路或起火!

• 有关标识和电源功率,请参阅产品背面或底部的型号

• 在将本产品连接到电源插座上之前,请确保电源电压与 产品背面或底部印刷的电压值相匹配。如果电压不同,

小心受伤或损坏本产品!

切勿将产品连接到电源插座上。

- 切勿将本产品或任何物体放在电源线或其它电子设备
- 如果在低于5℃的温度下运送了本产品,请先拆开产 品的包装并等待其温度达到室温,再将其连接至电源
- 本产品的部件可能由玻璃制造。请小心处理,以免受到 伤害或造成损坏。

小心过热!

小心污染!

• 切勿将本产品安装在封闭的空间内。务必在产品周围留 出至少 4 英寸的空间以便通风。确保窗帘或其它物体不 会遮挡产品上的通风槽。

• 请勿混合使用电池(旧电池与新电池或碳电池与碱性电

- 电池安装不正确会有爆炸危险。只能用相同或相当的型
- 号更换。 • 如果电池电量耗尽或遥控器长时间不用,请取下电池。
- 电池含有化学物质,因此应适当地进行处理。

吞咽电池的危险!

- 产品/遥控器可能包含纽扣式/按钮式电池,容易被 吞咽。始终将电池放在儿童接触不到的地方! 如不慎吞 咽, 电池可能导致严重受伤或死亡。摄入后 2 小时内可 能发生严重的内部烧伤。
- 如果您怀疑电池不慎被吞咽或位于体内的任何部位,请
- 更换电池时,请务必将所有新旧电池放在儿童接触不到
- 的地方。更换电池后,确保电池仓完全紧闭。 • 如果电池仓无法完全紧闭,请不要继续使用产品。放在 儿童接触不到的地方并联系制造商。



此款 || 类设备具有双重绝缘,不提供保护接地。

爱护产品

只能用微细纤维清洁布清洁本产品。





本产品采用可回收利用的高性能材料和组件制造而成。 弃置产品时,请不要将其与一般生活垃圾一同丢弃,应将其 交给政府指定的回收中心或回收。这样做有利于环保。

•此设备不得遭受水滴或水溅. •此设备上不得放置诸如花瓶一类的装满液体的物品. •接入本设备的有限网络天线必须与保护接地隔离,否 则可能会引起着火等危险,



2017 © Gibson Innovations Limited. All rights reserved. his product has been manufactured by, and is sold under the esponsibility of WOOX Innovations (Shanghai) Commercial Company Ltd.,and WOOX Innovations (Shanghai) Commercial Company Ltd., is the warrantor in relation to this product. Koninklijke

Specifications are subject to change without notice

Philips N.V.and are used under license.

CN-DTM380/88-UM-V2.0





English

Important

Read and understand all instructions before you use your product. If damage is caused by failure to follow instructions, the warranty does not apply.

Help and support

- For extensive online support, visit www.philips.com/support to:
- download the user manual and the quick start guide watch video tutorials (available only for selected models)
- find answers to frequently answered questions (FAQs) email us a question
- chat with our support representative. Follow the instructions on the website to select your language, and then enter your product model number.

Before you contact, note down the model number and serial number of your product. You can find this information on the back or bottom of your product.

Safety

Risk of electric shock or fire!

 Before you make or change any connections, make sure that all devices are disconnected from the power outlet.



- Never place the product and accessories near naked flames
- or other heat sources, including direct sunlight. Never insert objects into the ventilation slots or other
- openings on the product. Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily
- Batteries (battery pack or batteries installed) shall not be
- exposed to excessive heat such as sunshine, fire or the like. Disconnect the product from the power outlet before

lightning storms. When you disconnect the power cord, always pull the plug, never the cable.

Risk of short circuit or fire!

- For identification and supply ratings, see the type plate at the back or bottom of the product.
- Before you connect the product to the power outlet, ensure that the power voltage matches the value printed on the back or bottom of the product. Never connect the product to the power outlet if the voltage is different.

Risk of injury or damage to this product!

 Never place the product or any objects on power cords or on other electrical equipment.

- If the product is transported in temperatures below 5°C, unpack the product and wait until its temperature matches
- room temperature before connecting it to the power outlet. Parts of this product can be made of glass. Handle with care to avoid injury and damage.

Risk of overheating!

 Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Ensure curtains or other objects never cover the ventilation slots on the product.

Risk of contamination!

- Do not mix batteries (old and new or carbon and alkaine,
- Danger of explosion if batteries are incorrectly replaced. Replace only with the same or equivalent type.
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time. Batteries contain chemical substances, they should be

disposed of properly.

- Risk of swallowing batteries! • The product/remote control may contain a coin/button type battery, which can be swallowed. Keep the battery out of reach of children at all times! If swallowed, the battery can cause serious injury or death. Severe internal burns can occur
- within two hours of ingestion. • If you suspect that a battery has been swallowed or placed inside any part of the body, seek immediate medical attention.

batteries out of reach of children. Ensure that the battery compartment is completely secure after you replace the battery.

When you change the batteries, always keep all new and used

• If the battery compartment cannot be completely secured, discontinue use of the product. Keep out of reach of children and contact the manufacturer.




This is CLASS II apparatus with double insulation, and no protective earth provided.

Care for your product

Use only microfiber cloth to clean the product.

Care of the environment



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point or recycling. By doing this, you help to preserve the



ZH-CN 使用产品前,请阅读所有随附的安全信息

safety information

EN Before using your product, read all accompanying














ZH-CN 开机 **EN** Switch on this product













environment.

ZH-CN 蓝牙连接

EN Bluetooth Connection



