

Quick Start Guide

Step A *Setup*

Step B *Enjoy*

What's in the Box?

You should find these items upon opening the box.



Quick Start Guide



User manual



MW antenna



Remote Control



Pull out the insulation plastic sheet.

PHILIPS

Step A


Setup

Connection

- 1 For radio reception, connect the supplied AM antenna to the **MW aerial** terminal.
- 2 Connect the speaker wires to the **SPEAKERS** terminals.
- 3 Connect the power cord of the system to the AC power outlet.


Tip

It is unnecessary to connect the FM pigtail antenna since it is fixed to the main unit.



Setting the clock

- 1 In standby mode, press **PROG/CLOCK** button. The clock digits for the hours flash.
- 2 Press **◀◀ / ▶▶** to set the hours.
- 3 Press **PROG/CLOCK** again. The clock digits for the minutes flash.
- 4 Press **◀◀ / ▶▶** to set the minutes.
- 5 Press **PROG/CLOCK** to confirm the time.




Step B

Enjoy


Playing a disc

- 1 Select **CD** source.
- 2 Press **OPEN•CLOSE** on the top of the system to open the CD door.
- 3 Insert a disc with the printed side facing up and press down on **OPEN•CLOSE** to close the CD door.
- 4 Press **▶ II** to start playback.
- 5 Press **■** to stop playback.



Listening to radio

- 1 Select **TUNER** source.
- 2 Press **BAND TUNER** on the remote control to select your waveband.
- 3 Turn **TUNING** ● to tune to a station.



Tip

Detailed playback features and additional functions are described in the accompanied owner's manual.

