Register your product and get support at www.philips.com/support


XL490 XL495




Quick start guide










2 Get started

Configure your phone



- **1** When using your phone for the first time, you see a welcome message (country dependent).
- 2 Set the country and language if prompted.
- **3** Set the date and time.
- If the time is in 12-hour format, press
 ▲ 3 / ▼ to select [am] or [pm] (country dependent).

Charge your phone



70%
70% - 40%
40% - 10%

Flashing: low battery Scrolling: charging in progress

Call

- To make a call, press **(** or **(**) and dial the phone number.
- To answer a call, press **(** or **(**) when the phone rings.
- To end a call, press 🕿.

Adjust the earpiece volume

Press \blacktriangle or \blacktriangledown to adjust the volume during a call.

Set the direct keys

1 Enter the number, then press and hold **m1**, **m2** or **m3**.

- **2** Follow on-screen instructions.
- 3 To make a quick call from the record pre-saved in the direct key, press m1, m2 or m3 in standby mode, then press w.

Add a contact in the phonebook


1 Press [Menu].

2 Select [Phonebook] > [Add new].

3 Follow on-screen instructions.

Telephone answering machine 3 (XL495 only)

Listen to recorded messages



① To turn the answering machine on or off in standby mode, press 也.

(2) To delete the current message, press $\mathbf{\overline{D}}$.

③ To adjust the volume, press ● / ●).
 ④ To play the next message, press ●.

⑤ To play the previous message/replay the current message, press I
⑥ To start/stop listening, press ►■.

Note

• For more information, see the Telephone answering machine section in the user manual.

Record an announcement

- 1 Press [Menu].
- 2 Select [Answ. Machine] > [Announcement].
- 3 Follow on-screen instructions.

i



Refer to the user manual that came with your new phone or download the latest version from www.philips.com/support.

