Always there to help you Register your product and get support at www.philips.com/support



BT1300



ZH-CN 简明用户手册 EN Short User Manual





Specifications are subject to change without notice. 2014 © WOOX Innovations Limited. All rights reserved. Philips and the Philips' Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by WOOX Innovations Limited under license from

BT1300\_93\_Short User Manual\_V1.0



# 警告

- 切勿拆下本扬声器的外壳。
- 切勿润滑本扬声器的任何部件

注意事项

- 切勿将本扬声器放在其他电器设备上面。
- 应让本扬声器远离阳光直射、明火或高温。
- 请确保扬声器周围有足够的空间进行通风。
- 仅使用制造商指定的附件或配件。
- 不可将电池置于高温环境, 如阳光直射处、 明火或类似环境。
- 切勿将扬声器暴露在漏水或溅水环境下。
- 不要将任何危险源放在扬声器上(例如装 有液体的物体、点燃的蜡烛)。

• 铭牌(铭牌上的信息包括工作电压)位于主机背面,使 用前请先了解铭牌上的相关信息。

# 注意

如果用户未经 WOOX Innovations 的明确许可而 擅自对此设备进行更改或修改,则可能导致其 无权操作此设备。

## 爱护环境

### 弃置旧产品

本产品采用可回收利用的高性能材料和 组件制造而成。

弃置产品时,请不要将其与一般生活垃 圾一同丢弃, 应将其交给政府指定的回收中心 或回收。 这样做有利于环保。

# 注意

• 拆卸内置电池将使保修失效, 并可能

务必让专业人员拆卸产品中的内置

# 环境信息

已省去所有不必要的包装。 我们努力使包装易 于分为三种材料: 纸板(盒)、泡沫塑料(缓 冲物)和聚乙烯(袋、保护性泡沫片)。

您的系统包含可回收利用的材料(如果由专业 公司拆卸)。请遵守当地有关包装材料、废电 池和旧设备的处理的规定。

## 商标声明

SIG, Inc. 所有,WOOX Innovations 对这些字样和徽标的任何使用均属 合法。

### EN

# **Important**

# Warning

- Never remove the casing of this speaker.
- Never lubricate any part of this speaker.Never place this speaker on other electrical equipment.
- Keep this speaker away from direct sunlight, naked flames
- Make sure that there is enough free space around the speaker for ventilation.
- Only use attachments or accessories specified by the manufacturer.
- The battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- The speaker shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the speaker (e.g. liquid filled objects, lighted candles).



The type plate is located on the back of the product.

# Notice

Any changes or modifications made to this device that are not expressly approved by WOOX Innovations may void the user's authority to operate the equipment.

## Care of the environment

### Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point or recycling. By doing this, you help to preserve the environment.

# Caution

Removal of the built-in battery invalidates the warranty and may destroy the product.

Always bring your product to a professional to remove the built-in



### Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

### Trademark notice

The Bluetooth® word mark and Bluetooth logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by WOOX Innovations is under license.

部件名称	有害物质或元素 Hazardous Substance					
Name of the Parts	铅 (Pb, Lead)	汞 (Hg, Mercury)	镉 (Cd, cadmium)	六价铬(Chromium 6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
Housing 外壳	0	0	0	0	0	0
Loudspeakers 喇叭单元	0	0	0	0	0	0
PWBs 电路板组件	Х	0	0	0	0	0
Accessories (Cables) 附件 (电源线,连接线)	Х	0	0	0	0	0

本表格依据SJ/T 11364的规定编制。

The table is compiled according to SJ/T 11364.

- 〇:表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以下。 O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
- ×:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 标准规定的限量要求。
- X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.




This logo refers to the period (10 years)


电子信息产品中含有的有害物质或元素在正常使用的条件下不会发生外泄或突变,电子信息产品用户使 用该电子信息产品不会对环境造成严重污染或对其人身、财产造成严重 损害的期限。

This logo refers to the period ( 10 years ) during which the hazardous substances or elements contained in electronic information products will not leak or mutate so that the use of these [substances or elements] will not result in any severe environmental pollution, any bodily injury or damage to any assets.









ZH-CN 注:1) 使用之前,为内置电池充满电。 2) 使用后,请将开关滑动至 OFF 以关闭 扬声器。

### LED 指示灯行为


	充电中	充满电
"OFF" 模式	呈白色闪烁	关
"AUDIO IN"模式	呈白色闪烁	呈白色持续亮起
<b>"蓝牙"</b> 模式	呈蓝色闪烁或呈 蓝色持续亮起 (具体取决于蓝 牙连接状态)	呈蓝色闪烁或呈 蓝色持续亮起 (具体取决于蓝 牙连接状态)


Note: 1) Before use, fully charge the built-in battery. 2) After use, slide the switch to OFF to turn off the speaker.

## LED indicator behavior

	Under charging	Fully charged
<b>OFF</b> mode	Flashing white	Off
<b>Audio-in</b> mode	Flashing white	Solid white
<b>Bluetooth</b> mode	Flashing blue or solid blue (depending on Bluetooth connection status)	Flashing blue or solid blue (depending on Bluetooth connection status)

BT1300 93 SUM V1.0.indd 1 10/23/2014 2:16:30 PM







# **ZH-CN 1.** 将开关滑至 **3** 。

- → LED 指示灯呈蓝色闪烁。
- 2. 在您的蓝牙设备上,启用蓝牙并 搜索蓝牙设备。然后在设备上选 择 [Philips BT1300] 以开始配对并 连接。 如有必要,请输入默认密 码"0000"
  - → 连接成功后, 扬声器会发出两 声蜂鸣,蓝色蓝牙指示灯持 续亮起。
- 3. 播放蓝牙设备上的音频。
- 要调节音量,请使用蓝牙设备上 的音量控制。
- 要进入蓝牙配对模式,请按住**(**8) 两秒钟。
- → 当前蓝牙连接断开。

### 注:

- 本扬声器最多可记忆 4 个已配对 设备。
- 请远离任何其他可能造成干扰的 电子设备。


- **1.** Slide the switch to **3**.
  - → The LED indicator flashes blue.
  - 2. On your Bluetooth device, enable Bluetooth and search for Bluetooth devices. Then select [Philips BT1300] on your device to start pairing and connection. If necessary, enter default password "0000".
  - → After successful connection, the speaker beeps twice, and the LED indicator turns solid blue.
  - **3.** Play audio on the Bluetooth device.
  - To adjust volume, use the volume control on your Bluetooth device.
- To enter Bluetooth pairing mode, press and hold **(0** for two seconds.
  - → The current Bluetooth connection is disconnected.

### Note:

- The speaker can memorize a maximum of 4 paired devices.
- Keep away from any other electronic device that may cause interference.

**(**/\*)







**EN** After Bluetooth connection, you can control an incoming call

ZH-CN 蓝牙连接后,您可以使用此扬声器控制来电。

按下可接听来电。

按住可拒接来电。

通话时,按下可结束当前通话。

通话时, 按住可将通话转接至移动设备。

注意: 若有来电,音乐播放会暂停。



Press to answer an incoming call.


Press and hold to reject an incoming call.


During a call, press to end the current call.

During a call, press and hold to transfer the call to your

Note: Music play pauses when there is an incoming call.







ZH-CN 提示:要调节音量,请使用外部音频设备上的音量控制。

Tip: To adjust volume, use the volume control on your external audio device.



### ZH-CN 规格

# 功放器

额定输出功率	2瓦RMS
频率响应	80 -16000 赫兹,±3 dB
信噪比	>70 dBA
音频输入	300 毫伏 RMS

# 扬声器

蓝牙频段

蓝牙工作范围

扬声器阻抗	4 欧姆
扬声器驱动器	4.5 厘米全频
灵敏度	>81dB/m/W±3dB/m/W
7 5 N X	
蓝牙	
2 ( 3/1/2)	V3.0

2,4 GHz ~ 2,48 GHz

10 米 (开阔空间)

# 一般信息

电源	5 伏 == 0.5 安
(通过 USB 插孔)	
内置电池	锂聚合物电池(3.7 伏, 500 毫安时)
尺寸 - 主装置 (宽×高×厚)	55×55×55 毫米
重量 - 主装置	0.1 千克

# **Specifications**

Speaker Driver

Sensitivity

Amplifier	
Rated Output Power	2 W RMS
Frequency Response	80 -16000 Hz, ±3 dB
Signal to Noise Ratio	> 70 dBA
Audio-in Input	300 mV RMS
Speaker	
Speaker Impedance	4 ohm

4.5 cm full range


>81dB/m/W±3dB/m/W

### Bluetooth

Bluetooth Version	V3.0
Bluetooth Profile	HFP, HSP, A2DP
Bluetooth Frequency Brand	2.4 GHz ~ 2.48 GHz
Bluetooth Range	10 m (Free space)

# General information

Power Supply	
(through USB socket)	5 V === 0.5 A
Built-in Battery	Li-polymer battery (3.7 V, 500 mAh)
Dimensions - Main Unit (W x H x D)	55 × 55 × 55 mm
Weight - Main Unit	0.1 kg



ZH-CN 要下载完整用户手册,请访问 www.philips.com/support。

**EN** To download the full user manual, visit www.philips.com/support.





