

PHILIPS

CD Soundmachine

USB

Black/Gold

5W

PX3115G



Enjoy your music wherever you go

with USB direct

Want to enjoy the music collections stored at portable music player without using headphone? Plug the USB Direct socket to the Philips CD soundmachine and enjoy your favorite digital music through the powerful speakers - anytime, anywhere.

Easy to use

- 20-track CD programmable
- CD Shuffle/Repeat for personalized music enjoyment
- 20 preset tuning stations

Enjoy your music from different sources

- Play MP3-CD, CD and CD-R/RW
- FM/MW (AM) stereo tuner
- Audio-in for easy portable music playback
- USB Direct for MP3 music playback

Powerful sound you can hear and feel

- Dynamic Bass Boost for deep and dramatic sound
- 5W Total output power

Highlights

USB Direct for MP3 music


USB Direct for MP3 music playback

Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3")". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your



favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

20-track CD programmable

The CD programmable playback feature allows you to enjoy your favorite tracks in the sequence you want.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Sound

Output power: 2 x 2.5 W

Volume control: up/down

Sound system: stereo

Loudspeakers

No. of built-in speakers: 2

Connectivity

USB: USB host

Audio in (3.5mm)

Audio playback

Disc playback modes: fast forward/backward, next/previous album search, next/previous track search, repeat/shuffle/program

Playback media: CD, CD-R, CD-RW, MP3-CD

USB playback mode: fast forward/backward, next/previous track search, play/pause, repeat/shuffle/program

Tuner/Reception/Transmission

Antenna: FM antenna

Tuner bands: FM, MW (AM)

Convenience

Loader type: top

Display type: LCD display

Power

Battery type: C size (LR14)

Battery voltage: 1.5 V

Mains power: AC 110V-127V and 220-240V selectable

Power supply: AC or battery input

Number of batteries: 6

Accessories

Others: User Manual

Cables/Connection: power cord

Warranty: Warranty leaflet

Dimensions

Weight incl. Packaging: 1.9 kg

Product dimensions (WxDxH): 252 x 242 x 128 mm

Packaging dimensions (WxDxH): 280 x 160 x 260 mm

Product weight: 1.5 kg

