


6

Set the alarm timer
Cómo ajustar la hora de alarma
Programmation de l'alarme


Impostazione della sveglia
De wektijd instellen
Einstellen der Alarmzeit



7


Turn on/off the alarm timer
Activación/desactivación del
temporizador de alarma
Activation/désactivation de l'alarme

Attivazione/disattivazione della sveglia
De alarmtimer in- of uitschakelen
Ein-/Ausschalten des Alarm-Timers



www.philips.com/welcome

AJ1003



© Royal Philips Electronics N.V. 2010
All rights reserved.


Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

AJ1003_12_QSG_V1.0


100% recycled paper
100% papier recyclé

PHILIPS


- 1** Remove the protective tab
 Cómo quitar la pestaña protectora
 Retirez la languette de protection
 Rimozione della linguetta di plastic
 protettiva
 Het beschermlijpje verwijderen
 Schutzstreifen entfernen




- 2** Connect power
 Conexión de corriente
 Alimentation
 Collegamento dell'alimentazione
 Stroom aansluiten
 Anschließen an die Stromversorgung



- 4** Listen to radio
 Cómo escuchar la radio
 Ascolto della radio
 Radio luisteren
 Écoute de la radio
 Empfangen von Radiosendern



- 3** Set time and date
 Ajuste de hora y fecha
 Réglage de la date et de l'heure
- Impostazione di ora e data
 De datum en tijd instellen
 Radiosender manuell programmieren



- 5** Program radio stations automatically
 Programación automática de emisoras
 de radio
 Programmation automatique des stations
 de radio
- Programmazione automatica delle
 stazioni radio
 Radiozenders automatisch programmeren
 Automatisches Programmieren von
 Radiosendern

