

Philips CD Soundmachine

AZ102C

Program your favorite music

You take pleasure in the simple things in life and delight in convenience. The sleek and portable design lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable
- Line-in connection

Enjoy your music from different sources

- CD player
- FM/MW tuner for radio enjoyment

Rich and clear sound

• Dynamic Bass Boost for deep and dramatic sound



AZ102C/98

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- · Antenna: FM Antenna

Sound

- Output power (RMS): 2 x 1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary





Connectivity

• 3.5mm stereo line in

Power

- Mains power
- Battery type: LR14
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

 Included accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W \times H \times D): 284 \times 155 \times 264 mm
- Product dimensions (W \times H \times D): 262 \times 123 \times 245 mm
- Weight: 1.6 kg
- Weight incl. Packaging: 2 kg

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD Shuffle/Repeat

The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

FM/MW tuner

FM/MW (AM) stereo tuner

Line-in connection

Line-in connection



Issue date 2014-02-11

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 51186 EAN: 87 12581 47467 6

www.philips.com